

Jacket With Zipper - Sewing Pattern #2400

Recommendations on fabric: thin natural/mixed suiting fabrics.

You will also need: fusible interfacing; separating zipper.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Upper back - cut 2
2. Lower back - cut 1 on fold
3. Lower front - cut 2
4. Upper front - cut 2
5. Center front facing — cut 2
6. Back neck facing - cut 1
7. Upper sleeve - cut 2
8. Lower sleeve - cut 2

Fusible interfacing:

1. Center front facing — cut 2



2. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing to corresponding pieces, and also to seam allowances along hem of garment and hem of sleeves.
2. Sew shoulder and waist darts on upper backs, press bulk towards center. Sew center back seam, press seam allowances towards left and serge. Sew upper back to lower back, press seam allowances towards top and serge.
3. Sew darts on front, cut away the bulk of the dart leaving 1 cm, press towards center and serge. Make and baste pleats on lower fronts. Sew upper front to lower front, press seam allowances towards top and serge.
4. Sew shoulder and side seams, press seam allowances towards back and serge.
5. Sew side seams of back neckline facing and buttonstands, press seam apart. Serge outer edge. Pin center front facings and facing onto Shell, right sides together, insert zipper between the pieces and sew center front edge, neckline and lower corner. Trim away corners, clip into curves. Fold center front facings (buttonstands) onto right side, straighten seams, press.
6. Sew elbow and front sleeve seam, serge and press. Sew sleeves into armholes matching notches, serge and press.
7. Serge lower edge of garment and lower edge of sleeve, press onto wrong side and topstitch.

TECHNICAL DRAWING:

