

Coat With Short Sleeve - Sewing Pattern #2409

Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: lining; fusible interfacing; 1 button.

Seam allowances: all seams 1 cm. Seam allowance along lower edge of garment and lower edge of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back — cut 1 on fold
2. Center front - cut 2
3. Front side - cut 2
4. Back neck facing - cut 1
5. Sleeve - cut 2
6. Center front facing - cut 2
7. Pocket facing - cut 2

8. Belt – cut 1

Lining:

1. Back lining – cut 2
2. Front lining – cut 2
3. Pocket bag – cut 4

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Pocket facing – cut 2

Attention! Lining is cut using pattern blocks for Main fabric except for the width of center front facing and back neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusible interfacing to the 1-piece underlay piece on pocket.
2. Sew pocket bag to the 1-piece underlay piece of pocket on side front. Press seam allowance towards bottom. Sew pocket bag to center front, clipping into seam allowance near corner. Press facing onto wrong side. Sew pocket bag to pocket facing on Front. Press seam allowance towards bottom. Sew a decorative stitch along pocket opening.
3. Sew front side to front, slashing seam allowances in the corner of center front and pocket. Press towards center part. Sew pocket bag along the center and lower edges. Sew a decorative stitch along the princess seam at 0.5 cm from seam.
4. Sew shoulder seams. Press seam apart. Sew in sleeves. Press towards sleeve. Sew a decorative stitch along the seam at 0.5 cm. Sew side seams and sleeve seams, pocket lining should be sewn into side seam. Press seams towards back.
5. Sew shoulder seams of buttonstands and facings. Press seam apart.
6. Place center front facing onto front right sides together and sew along center front edge and back neckline. Clip seam allowances, fold buttonstand towards wrong side and press.
7. Sew seams on lining, leaving an opening in left side seam.
8. Sew lining to buttonstands and facing. Sew lower edge of lining to hem of garment. Sew lining to hem of sleeve. Turn right side out through the opening. Sew the opening closed.
9. Fold belt in half lengthwise, sew the shorter and one longer sides, leaving an opening for turning. Trim away

corners, turn right side out and press.

10. Make button loop on right front. Sew on button.

TECHNICAL DRAWING:

