

Short Jacket - Sewing Pattern #2419

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment - 2.5 cm. Seam allowance for hem of sleeve - 2.5 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Center front - cut 2
4. Side front - cut 2
5. Lower collar - cut 1
6. Upper collar - cut 1
7. Center front facing - cut 2

8. Back neck facing – cut 1
9. Sleeve – cut 2

Attention: lining for front and back is cut using the pattern blocks for main fabric except for the width of the center front facing and back neckline facing.

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Sleeve – cut 2

Fusible interfacing:

1. Center front – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing. Apply a strap of interfacing 1 cm wide to the fold line of lapels on fronts (fusible interfacing).
2. Sew center back seam, press seam apart. Sew side backs to center back. Press towards center.
3. Sew side front to center front. Press towards center.
4. Sew shoulder and side seams. Press seam apart.
5. Pin upper collar to lower collar and sew corners and fall. Start and stop sewing exactly at the marked line of the seam between collar and garment. Trim away corners, clip into seam allowance near notch. Turn the collar right side out, straighten and press.
6. Sew and press apart shoulder seams of back neckline facing and buttonstand.
7. Place center front facing onto front right sides together, pin together and sew along the center front edge. Sew upwards up to the notch marking the end of collar seam.
8. Sew lower collar into neckline of jacket, sew upper collar into neckline of back facing and center front facing. Press seam allowances of the collar seam apart and slipstitch them together close to the seam.
9. Sew sleeve seam, press towards back part. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew on shoulder pads.

10. Hem of sleeve and of jacket press onto wrong side.
11. Sew seams on lining, leaving an opening in left sleeve. Sew lining to buttonstands and facing. Sew lining to hem of jacket and hem of sleeve.
12. Turn jacket right side out through the opening. Sew the opening closed.

TECHNICAL DRAWING:

