

Blouse With Sleeve With Flounce - Sewing Pattern #2424

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing, 5 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment - 2 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Front - cut 2
3. Sleeve - cut 2
4. Cuff - cut 4
5. Center front facing - cut 2
6. Back neck facing - cut 1

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Cuff – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back and front, press the bulk of waist darts towards center, press bulk of bust darts towards top. Sew center back seam, press towards left and serge.
3. Sew side and shoulder seams, press seams towards back and serge.
4. Sew shoulder edges of center front facings and back neckline facing, press seam apart. Serge outer edge. Pin center front facings onto shell right sides together and sew center front edges, front neckline and back neckline. Clip into curves, trim away corners, fold center front facings and neckline facing onto wrong side, straighten, press. Slipstitch to garment along the shoulder seams.
5. Sew sleeve seam, press towards back and serge. Sew sleeves into armholes, serge and press.
6. Pin cuffs together, right sides together and sew outer edge. Clip into curves, turn the piece right side out, straighten, press. Pin cuff to sleeve, right sides together, and sew. Press seam allowances onto sleeve, serge.
7. Serge hem of garment, press onto wrong side and topstitch.
8. Make buttonholes on right front, sew on buttons on left front.

TECHNICAL DRAWING:

