

Sewing Pattern — Dress 4275

Recommendations on fabric: fabric suitable for dresses

You will also need: fusing, blind zipper

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: all seams - 1 cm; along the vent – 6 cm; hem of the dress – 2.0 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Main fabric:

1. Back yoke - 1 detail
2. Upper back part - 2 details
3. Central part of the back - 1 detail
4. Lower part of the back - 2 details
5. Front part yoke - 2 details
6. Central upper part of the front - 2 details
7. Side upper part of the front - 2 details
8. Central part of the front - 1 detail
9. Front part inset - 1 detail
10. Lower part of the front - 1 detail
11. Lapel - 4 details
12. Stand-up collar - 2 details
13. Sleeve - 2 details
14. Sleeve placket – 2 details
15. Front neckline facing – 2 details

Fusing:

1. Lapel – 2 details
2. Stand-up collar - 1 detail
3. Front neckline facing – 2 details

INSTRUCTIONS:

1. Apply fusing to details.
2. Sew darts on upper and lower parts of the back, press depths towards center.
3. Sew center edge of upper part of the back, press seam onto left side and serge. Stitch yoke to upper part of the back, press seam allowances upwards and serge.
4. Cut off 5 cm on left lower part of the back, along vertical edge of the vent. Apply fusing to wrong side of the vent on both details of lower part of the back. Mark center seam line (vent fold line) on the right side. Press left part on vent fold line, on right part press only seam allowance of right side of the vent (6 cm) onto wrong side. Align details on center seam and fix along top edge of the vent. Serge center edge of back part separately on each detail. Serge seam allowances of the vent. Sew center edge of back part from top edge up to vent corner. Slash the corner of vent seam allowance on right part. Press apart seam allowances of center seam, press seam allowances of the vent and fix them on right side with machine stitch.
5. Stitch center part of the back to upper part, press seam onto central part and serge. Stitch lower part of the back to central part, press seam onto central part and serge.
6. Fold lapel details right sides together and overstitch outer edge. Turn detail right side out, straighten, press.
7. Sew princess edges on upper details of the front. Press seam allowances towards center and serge. Put the lapel onto wrong side of upper front part and stitch. Serge seam allowances. Turn the lapel onto right side, straighten and press. Fix the lapel to the front along top and lower edges.
8. Stitch yoke to upper part of the front, press seam allowances upwards and serge. Put right front part onto left and fix along the lower edge.
9. Make and fasten pleats on lower front part. Stitch inset of the front to lower part, press seam allowances upwards and serge.
10. Stitch central part of the front to upper part, press seam onto central part and serge. Stitch lower part of the front to central part, press seam onto central part and serge.
11. Fold details of stand-up collar right sides together and overstitch upper edge. Slash seam allowances, turn stand-up collar right side out, straighten, press. Sew outer stand-up part of collar into the back part neckline, turn inside seam allowance of inner stand-up collar and topstitch into connecting seam.
12. Serge outer edge of front part neckline facing. Fold the front part neckline facing with front part and overstitch the section from shoulder seam up to marker. Start and finish the stitch exactly near marked line of shoulder seam. Slash seam allowances on rounded parts, slash away in corner.
13. Sew shoulder seams, placing shoulder edge of back part between shoulder edge of front part and facing. Press and serge seam allowances. Turn the neckline facing wrong side out, straighten, press.
14. Serge separately left side edge. Sew left side edge, leaving a section for zipper unsewn. Press apart the seam. Sew in zipper. Sew right side edge, press seam onto back part and serge.
15. Fold sleeve placket in half lengthwise wrong sides together. Stitch placket to lower edge of sleeve, press seam onto the sleeve and serge. Sew sleeve into the armhole, slash seam allowances near notches, press and serge.
16. Cut bias tape of 4 cm wide and as long as lower part of the armhole + 6 cm. Fold bias tape in half lengthwise wrong sides together and press. Fold the bias tape with the edge of the armhole on right sides, leaving tails, and overstitch. Turn bias tape onto wrong side, slash seams and topstitch along the fold onto main detail. Press the seam.
17. Serge seam allowance of the dress hem, press onto wrong side and undersew with invisible stitches.

TECHNICAL DRAWING:

