

Short Jacket - Sewing Pattern #2477

Recommendations on fabric: thin coat or natural/mixed suiting fabrics.

You will also need: fusible interfacing, decorative closing.

Seam allowances: all seams 1 cm. Seam allowance along the lower edge on back and on side front - 2.5 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Side front - cut 2
3. Center front - cut 4
4. Cuff - cut 2

Fusible interfacing:

1. Center front - cut 2

2. Cuff - cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew center back seam. Serge seam and press towards left.
3. Sew upper edge of sleeve. Serge seams and press towards back.
4. Sew side seams and sleeve seams. Serge seams and press towards back.
5. Serge the seam allowance along the hem, turn inside and topstitch.(or finish with hidden stitches).
6. Pin center fronts together, right sides together and sew center collar seam. Press seam apart. Pin center pieces together, right sides together and sew center front edge and lower edges. Clip seam allowances, trim away corners. Pin the outer side of the center piece onto garment and sew along the center front edge and the neckline. Fold inside the seam allowance of the inner part and stitch in the ditch.
7. Sew cuff into a ring. Press seam apart. Pin the cuff onto sleeve, right sides together and sew. Fold cuff onto wrong side and press. Seam Allowance cuffs turn under at 1 cm and topstitch onto sleeve.
8. Sew on decorative closure.

TECHNICAL DRAWING:

