

## Sewing Pattern — Blouse 5986

Recommendations on fabric: fabric suitable for blouses  
(cotton, viscose, polyester)

You will also need: fusible interfacing, 12 buttons.

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: hem of the garment – 2 cm, all other seams – 1 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



### **CUTTING:**

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

#### Main fabric:

1. Central back - 2 details
2. Side back - 2 details
3. Front yoke - 2 details
4. Front inset - 2 details
5. Side front - 2 details
6. Central front - 2 details
7. Left front placket – 1 detail
8. Right front placket – 1 detail
9. Stand collar – 2 details
10. Stand collar placket — 1 detail
11. Stand collar flap — 2 details
12. Sleeve – 2 details
13. Cuff – 2 details
14. Cuff placket - 4 details
15. Cuff flap– 4 details

Interfacing:

1. Cuff – 2 details
2. Stand collar – 1 detail
3. Cuff placket - 2 details
4. Cuff flap – 2 details
5. Stand collar flap — 1 detail

**INSTRUCTIONS:**

1. Apply interfacing to corresponding details.
2. Place stand collar flap details right sides together and overstitch on side and lower sides. Slash seam allowances in corners, turn flap right side out, straighten, press.
3. Serge top and side edges of stand collar placket, press onto wrong side and topstitch. Make on placket evenly distributed pleats. Place stand collar details right sides together, insert placket (from mark up to mark) and flap between them and overstitch on outer contour and sides, overstitching at the same time section of lower edge up to marker. Slash seam allowances near mark. Turn stand collar right side out, straighten seams, press.
4. Sew princess seams on back, press seam allowances toward center and serge. Sew center edge of back, press seam onto left side and serge.
5. On inset details make and stitch pleats. Depths are turned toward shoulder seam.
6. Sew princess edges of front, press seam allowances toward center and serge. Stitch yoke to inset, press seam onto yoke and serge. Stitch inset to front, press seam onto front and serge.
7. Right front: apply fusing to right placket from edge up to line «inner edge of panel» from side of buttonholes marking. Stitch right placket to front, press seam onto placket. Press placket inside onto wrong side on lines «stand edge» and «stand edge of blind panel». Topstitch placket into connecting seam. Turn inner part of placket toward facing/buttonstand, press. Left front: stitch left placket to front, press seam onto placket. Turn inner edge inside at 1 cm and topstitch into connecting seam.
8. Sew shoulder and side edges, press seam onto back and serge.
9. Sew outer stand collar into the neckline, turn open edge of inner stand collar and topstitch into outer stand collar connecting seam.
10. Cut a bias tape 18\*3 cm to pipe the slit of sleeve. Mark on sleeve a closure line, slit sleeve on the line. Lay sleeve on slit line into straight line and overstitch slit with bound seam with closed edge. Piping is 0.5 – 0.7 cm wide. The width of seam on slit length is 0.5 – 0.7 cm, in top part of slit it goes to 0.2 cm. Sew and serge edges of sleeves. Stitch loosely along the edge of sleeve and gather ruffles.
11. Stitch cuff plackets to cuff, press seam onto placket. Fold cuffs in half lengthwise right sides together and overstitch short side and placket ledges from one side, as well as short side and upper edge up to mark from other side. Slash seam allowances near mark. Turn cuffs out and press.
12. Fold cuff flap details right sides together and overstitch on side and lower sides. Slash seam allowances in corners, turn right side out, straighten, press.
13. Stitch outer side of cuff to sleeve, inserting flap between them. Turn inside inner side of cuff and topstitch into connecting seam.
14. Stitch loosely along top of rounded part and gather ruffles. Sew sleeve into armhole. Press and serge seam.
15. Press hem of the garment to wrong side twice at 1 cm and topstitch.
16. Make buttonholes on right placket, stand collar, cuffs and flaps. Sew buttons.

**TECHNICAL DRAWING:**

