

Coat With 3 Buttons - Sewing Pattern #2499

Recommendations on fabric: natural/mixed fabrics suitable for coats.

You will also need: fusible interfacing; lining; 3 big buttons; hidden button; shoulder pads, sleeve heads.

Seam allowances: all seams 1 cm. Seam allowance for hem of coat and hem of sleeve 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Center front - cut 2
4. Side front - cut 2
5. Upper sleeve - cut 2
6. Lower sleeve - cut 2

7. Back neck facing – cut 1
8. Center front facing – cut 2

Lining:

1. Center back – cut 2
2. Center front – cut 2
3. Side back – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2

Fusible interfacing: center front, back neck facing, center front facing.

Attention: lining is cut using pattern blocks for self fabric except for the area of center front facing and back neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back. Press bulk towards center. Sew side backs to center back. Press seam apart. Sew center back seam. Press seam apart.
3. Sew dart on center front. Slash dart in half lengthwise and press apart. Sew side fronts to front. Seam Allowances press apart.
4. Sew side seams of coat and press apart. Clip into seam allowance in the corner near shoulder seam. Sew collar seam. Press seam apart. Sew shoulder seams, sewing collar into the neckline at the same time.
5. Sew the elbow seam of the sleeve and press it apart. Sew and press apart front sleeve seam. Sew sleeves into armholes matching notches. Sew shoulder pads, sew sleeve heads.
6. Sew seams on lining and sew in sleeves, leaving an opening for turning in front right sleeve seam. Sew shoulder seams of buttonstands and facings, clipping into seam allowances near corners. Sew collar seam on center front facings. Press seam apart. Sew collar into neckline. Press seam apart. Sew lining to buttonstands and facing.
7. Place center front facing onto front right sides together, pin together and sew along center front edge and along the hem. Sew lining to hem of sleeve. Turn coat right side out through the opening. Slip stitch seam allowances along the seams of inner and outer collars together. Sew the opening in sleeve closed. Sew a decorative stitch along center front edge and collar at 0.5 cm from the edge.

8. Make buttonholes on right front. Sew on buttons on the left front. Make the inner button hole. Sew on inner button.

TECHNICAL DRAWING:

