

## Long Jacket - Sewing Pattern #2498

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads; 3 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.0 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back - cut 2
2. Front yoke - cut 2
3. Front - cut 2
4. Upper sleeve - cut 2
5. Lower sleeve - cut 2
6. Center front facing - cut 2
7. Back neck facing - cut 1

8. Flap – cut 2
9. Pocket frame – cut 4

Lining:

1. Back – cut 2
2. Front lining – cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2
5. Smaller pocket bag – cut 2
6. Bigger pocket bag – cut 2

Attention: Back from lining is cut using the pattern block for Back on main fabric, except for the width of the back neckline facing.

Fusible interfacing:

1. Front yoke – cut 2
2. Front – cut 2
3. Center front facing – cut 2
4. Back neck facing – cut 1

## **INSTRUCTIONS:**

1. Apply fusible interfacing. Cut a tape from fusible interfacing and apply along edge of back neckline. Apply fusible interfacing to the seam allowances along hem of garment and hem of sleeve.
2. Sew darts on back and front, press bulk towards center.
3. Apply fusible interfacing to vent areas on the back on the wrong side. Mark center seam line (vent fold-line) from the right side. Press left back along fold line of vent. Align pieces along center seam. Sew center back seam and corner of vent, stop stitching when the distance from vertical edge of vent is 1 cm. Clip into seam allowance of vent in corner on right part. Press apart center seam, press seam allowances of vent and topstitch them from the right side using machine stitch.
4. Pin together flaps in half lengthwise right sides together and sew side edges. Trim corners, turn right side out flap onto right side, straighten, press.
5. Mark the position of pocket. Fold pocket facings in half wrong sides together and press. Mark the stitch line on pocket facing parallel to the facing fold line. Mark an additional line on pocket flap for sewing it parallel to the upper edge of pocket flap, verifying the width of pocket flap all along. Mark additional lines parallel to pocket opening for sewing pocket flap and pocket facings. Sew pocket lining to pocket flap. Sew facings to front. Finish stitching at the guidance lines that you marked near pockets. Check your work on the wrong side (stitch lines should be parallel). Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn facings onto wrong side through the resulting opening, straighten edges,

adjust ends of facings so that the pressed fold lines of the facings meet one another. Sew a double back stitch lines near corners to fix ends of pockets. Insert flap into pocket and sew it to upper pocket facing. Pin lower lining of pocket onto the seam of lower facing and stitch-in-the-ditch; trim and sew pocket lining.

6. Pin center front facing to front, right sides together, sew the edge of lapel and center front edge, clip into curves, fold center front facing onto wrong side, straighten, press. Clip seam allowance center front facings in the corner у начала of lapel, fold lapel onto front according to marked line перегиба and baste together along upper edge.

7. Sew yoke to front (start and stop stitching exactly at the marked line of neckline), press seam allowances towards top. Sew and press apart shoulder seams.

8. Sew and press apart the shoulder seams on center front facings and neckline facing. Pin facing to garment, right sides together, and sew the areas on front from lapel to shoulder edge, and the back neckline edge. Clip into curves, turn facing under, press.

9. Sew and press apart side seams.

10. Sew the elbow seam of the sleeve and press it apart, adjusting ease on upper part of sleeve and matching notches. Press hem of sleeve. Fold away seam allowance on hem, sew and press apart front sleeve seam.

11. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.

12. Sew seams on lining and sew in sleeves, leaving an opening for turning in left elbow seam. Sew lining to inner edges of center front facings and of facing.

13. Sew lining to lower edge of garment and lower edge of sleeve. Turn jacket right side out. Sew the opening closed.

14. On right front make button loop, on left front sew on button. Make the inner button hole and sew on inner button. Sew a decorative button onto right front.

## TECHNICAL DRAWING:

