

Jacket Without Closure - Sewing Pattern #2507

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; fusible interfacing; shoulder pads.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Front - cut 2
3. Upper sleeve - cut 2
4. Lower sleeve - cut 2
5. Placket - cut 2
6. Collar - cut 1
7. Back neck facing - cut 1

8. Center front facing – cut 2

Lining:

1. Back – cut 2
2. Front – cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2

Fusible interfacing:

1. Placket – cut 2
2. Collar – cut 1
3. Center front facing – cut 2
4. Back neck facing – cut 1

Lining is cut using pattern blocks for front and back for the main fabric except for the width of center front facing and facing.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back Press bulk towards center. Sew center back seam, press seam apart.
3. Sew shoulder and side seams. Press seam apart.
4. Fold placket in half lengthwise right sides together and sew lower and upper corners. Trim seam allowances, turn right side out and press. Fold collar in half lengthwise right sides together and sew corners. Trim seam allowances, turn right side out and press.
5. Sew placket to center front edge of the jacket. Sew collar into neckline of jacket. Press towards the main piece.
6. Sew sleeve seam, press towards back part. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew on shoulder pads.

Sew shoulder seams facings and center front facings. Press seam apart. Sew center front facings and facing to the collar and to the placket. Clip seam allowances, and press.

7. Hem of sleeve and of jacket press onto wrong side.
8. Sew seams on lining, leaving an opening in left sleeve. Sew lining to center front edges and to neckline. Sew

lining to center front edges, to facing, to hem of jacket and to sleeves.

9. Turn jacket right side out through the opening. Sew the opening closed.

TECHNICAL DRAWING:

