

Coat With Hood - Sewing Pattern #2523

Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: fusible interfacing; lining; thin shoulder pads.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Center front - cut 2
5. Center front facing — cut 2
6. Back neck facing - cut 1
7. Upper sleeve - cut 2

8. Lower sleeve – cut 2
9. Lower front — cut 2

Lining is cut using the pattern blocks for self fabric, except for the width of back neckline facing.

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Front lining – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Lower front — cut 2
8. Pocket bag – cut 4

Fusible interfacing: center front, center front facing (except for the hood), back neck facing.

INSTRUCTIONS:

1. Apply fusible interfacing. Cut a tape from fusible interfacing and apply along edge of back neckline.
2. Sew and press apart princess seams on back. Sew center back seam. Press seam apart.
3. Sew princess seam on front. Press seam apart. Sew pocket lining to upper front. Start and stop stitching exactly at the marked line of the beginning and the end of pocket. Press towards top. Sew pocket lining to lower front. Start and stop stitching exactly at the marked seamline. Sew lower part to front from center front to pocket, and from pocket to side seam. Press seam apart. Sew pocket bag. Press seam.
4. Sew the hood seam. Press seam apart. Clip into seam allowances in the corner of the shoulder edge. Sew hood into back neckline. Sew shoulder seams of coat. Press seam apart.
5. Sew side seams of the coat. Press seam apart.
6. Sew elbow seam on sleeve. Press elbow seam apart, press hem of sleeve. Sew and press apart front sleeve seam.
7. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.
8. Sew and press apart shoulder seams of back neckline facing and buttonstand, clipping into seam allowance near corner. Sew hood seam. Sew dart on front lining. Sew together pieces of lining in the same way as you have sewn pieces from main fabric, leaving an opening in left elbow seam of sleeve. Sew lining to facing and

buttonstands.

9. Pin lining to coat, right sides together, matching outer edges. Sew lining to center front edge and to hood. Sew lining to hem of coat. Sew lining to hem of sleeve. Turn coat right side out through the opening. Baste lining to Shell along waist seam on front. Sew the opening closed.

10. Make button loop and sew on button.

TECHNICAL DRAWING:

