

## Top With Wrap Effect And A Patch Pocket - Sewing Pattern #2530

Recommendations on fabric: natural/mixed fabrics suitable for dresses or blouses.

You will also need: fusible interfacing; 1 button; 1 decorative button.

Seam allowances: all seams 1 cm; seam allowance along the outer edges of the left front and of the right front – 1.2 cm; seam allowance for hem of garment – 1.2 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



## CUTTING:

### Note on cutting:

On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back yoke - cut 2
2. Back - cut 1 on fold
3. Front yoke - cut 1
4. Right front - cut 1
5. Left front - cut 1
6. Flap - cut 2

- 7. Pocket facing - cut 2
- 8. Pocket bag - cut 2

Fusible interfacing:

- 1. Flap – cut 1
- 2. Pocket facing - cut 2

## INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on fronts, press bulk towards top.
3. Serge the outer edges and the lower edges of the left front and the right front. Press seam allowances onto wrong side and topstitch.
4. Pin flaps together right sides together and sew side and lower edges. Clip seam allowances, turn right side out flap onto right side, straighten, press.
5. Mark the position of pocket. Fold pocket facings in half lengthwise wrong sides together and press. Mark the stitch line on pocket facing parallel to the facing fold line. Mark an additional line on pocket flap for sewing it parallel to the upper edge of pocket flap, verifying the width of pocket flap all along. Mark additional lines parallel to pocket opening for sewing pocket flap and pocket facings. Sew pocket lining to pocket flap. Sew facings to front. Finish stitching at the guidance lines that you marked near pockets. Check your work on the wrong side (stitch lines should be parallel). Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn facings onto wrong side through the resulting opening, straighten edges, adjust ends of facings so that the pressed fold lines of the facings meet one another. Sew a double back stitch lines near corners to fix ends of pockets. Insert flap into pocket and sew it to upper pocket facing. Sew the lower lining of the pocket into the seam of the lower facing. Trim and sew together the pocket lining, serge.
6. Fold inside the outer edge of the right front near the mark. Put right front onto left front and baste together along the upper edges. Sew yoke to front, press towards top and serge.
7. Serge the central edges of the back yokes, press onto wrong side and topstitch. Sew back yokes to back, press towards top and serge.
8. Sew shoulder seams, press seams towards back and serge.
9. Cut (or take ready) bias tape, its width should equal 2.5 cm and its length should equal 10 cm for loop buttonhole. Fold tape in half lengthwise right sides together and stitch at 0.3 cm from fold. Cut away seam allowances close to seam, turn tape right side out and straighten rolled hem. Adjust length of the loop.

10. Cut (or take ready) bias tape, its width should equal 4 cm and length should equal the length of neckline + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to neckline from the right side, leaving loose ends, and sew. Fold bias tape onto wrong side, clip into seam allowances and topstitch onto main piece along the seam. Press seam. Sew button loop to the left back yoke.
11. Cut (or take ready) bias tape, its width should equal 4 cm and length should equal the length of armhole + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto armhole edge from the right side, leaving loose ends, and sew. Fold bias tape onto wrong side, clip into seam allowances and topstitch onto main piece along the seam. Press seam.
12. Sew side seams (the back is longer than the front by the width of the lower seam allowance), press seams towards back and serge.
13. Serge the seam allowance along the hem on back, press onto wrong side and topstitch.
14. Sew button to right back yoke. Sew on button on the right front.

## TECHNICAL DRAWING:

