

Blouse With Embroidery - Sewing Pattern #2532

Recommendations on fabric: natural/mixed fabrics suitable for blouses. For Example, embroidered cotton.

You will also need: fusible interfacing.

Seam allowances: all seams 1 cm. Seam allowance along the center edge of the front – 0 cm. Seam allowance along the lower edge of the garment – 1.5 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Yoke - cut 1
3. Front - cut 2
4. Sleeve - cut 2
5. Stand collar — cut 2
6. Cuff - cut 2

Fusible interfacing:

1. Stand collar – cut 1
2. Cuff – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew a gathering stitch along upper edge of back, between the markings and gather fullness. Sew yoke to back, press towards top and serge.
3. Sew darts on front, press bulk towards top.
4. Cut a bias tape from self fabric (or take ready), its width should equal 4 cm and its length should equal the length of the center front edge + 4 cm. Sew the bias tape to the center front edge (sew to the edge, fold onto wrong side, fold inside the open edge and topstitch into the seam). Put right front onto left front, matching center lines, and topstitch into the seam of the bias tape.
5. Sew side and shoulder seams, press seams towards back and serge.
6. Pin stand collars together right sides together and sew outer edges. Start and stop sewing exactly at the marked line of seam. Clip into curves, turn stand collar right side out and press.
7. Sew outer stand collar into neckline, press seam allowances at stand collar. Turn under the raw edge of inner stand collar and stitch in the ditch.
8. Sew sleeve seam, press seams towards back and serge. Sew a gathering stitch along the lower edge of garment and gather fullness. Sew sleeves into armholes, serge and press.
9. Sew cuff into a ring, press seam apart. Fold cuff in half lengthwise and press right side out. Sew the outer side of cuff to the sleeve, press towards cuff. Fold inside the open edge of the inner side of the cuff and topstitch into seam of.
10. Serge seam allowance along hem of garment, press onto wrong side and topstitch.

TECHNICAL DRAWING:

