

Wrap Jacket With Decorative Sleeve - Sewing Pattern #2568

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads; buckle;
1 button; 1 inner button.

Seam allowances: all seams 1 cm. Seam allowance for hem of
garment and hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Center front - cut 2
5. Sleeve - cut 2
6. Center front facing - cut 2
7. Back neck facing - cut 1

8. Belt – cut 1

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center front – cut 2
5. Sleeve – cut 2

Attention: The front piece and the back piece from lining fabric are cut using the sewing patterns for the main fabric, except for the width of the back neckline facing and the center front facing correspondingly.

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Belt – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Fold belt in half lengthwise right sides together and sew along long side and one short side. Turn the piece right side out, straighten, press.
3. Sew side backs to center back, press the seam apart. Sew the center back seam, press the seam apart. Sew side fronts to front, press the seam apart.
4. Sew the shoulder edges and the side edges, press the seam apart.
5. Sew side seams of back neckline facing and central front facings, press seam apart. Pin the central front facings and the facings onto front, right sides together, pin together and sew the center front edge, the neckline and the lower center front corner, inserting the belt on the right side. Trim away corners, clip into curves. Topstitch the central front seam allowance onto center front facing. Place stitch line at 0,2 cm from seam. Turn center front facings right side out onto right side, straighten seams. Press lower edge of garment.
6. Sew the elbow dart on sleeve (if the pattern has it), press bulk towards top. Sew the darts on the sleeve cap, press the bulk. Press the hem of sleeve. Fold away seam allowance on hem, sew and press the sleeve seam apart.
7. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.
8. Sew seams on lining and sew in sleeves, leaving an opening for turning in left elbow seam. Sew lining to

inner edges of the central front facings and to back neckline facing.

9. Sew lining to lower edge of garment and lower edge of sleeve. Turn jacket right side out. Sew the opening closed.

10. Make buttonhole on belt. Sew on button. On left front make a button hole, sew on a hidden button correspondingly.

TECHNICAL DRAWING:

