

## Dress With False Wrap - Sewing Pattern #2561

Recommendations on fabric: natural/mixed fabrics with elastane suitable for dresses.

You will also need: fusible interfacing, dress zipper; decorative button.

Seam allowances: all seams 1 cm. Seam allowance along lower edge of garment and lower edge of sleeve - 2 cm. Seam allowance along the neckline edge and along the center edge of the decorative piece - 1.5 cm.

Attention: Pattern blocks have markings and texts from the right side. Take this into account when cutting the fabric-some of the pattern blocks need to be laid onto fabric with their wrong side on top.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

## CUTTING:

### Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Front - cut 1



3. Front neck facing - cut 1
4. Back neck facing - cut 2
5. Sleeve - cut 2
6. Front decorative piece - cut 1

Fusible interfacing:

1. Front neck facing - cut 1
2. Back neck facing - cut 2

## **INSTRUCTIONS:**

1. Apply fusible interfacing. Apply a strap of fusible interfacing onto the neckline edge and onto the center edge of the decorative piece.
2. Sew darts on back, press the inner part towards center. Serge the center back edges separately. Sew center back seam from notch for zipper to bottom. Seam Allowances press apart. Sew in zipper.
3. Sew darts on front. Press bulk of bust darts towards top, press bulk of waist darts towards center.
4. Sew the dart on the decorative piece. Press bulk towards top. Serge the seam allowance along the neckline, the center edge and the lower edge of the decorative piece. Turn seam allowances inside and topstitch. Pin the decorative front piece onto the right side of front and baste together along the side edges and the shoulder edges.
5. Sew side and shoulder seams. Press seams towards back and serge.
6. Sew shoulder seams of facings. Seam Allowances press apart. Serge the outer edge. Pin facing onto main piece, right sides together and sew neckline. Clip seam allowances, trim away corners, fold facings onto wrong side and press. Slipstitch center seam allowances on facing to zipper tape. Baste together along the shoulder edges.
7. Sew sleeve seam. Serge and press towards back. Sew sleeves into armholes. Serge and press.
8. Serge hem and hem of sleeve. Press onto wrong side and topstitch.
9. Make a buttonhole and sew on button.

## **TECHNICAL DRAWING:**

