

Blouse With One-Piece Sleeve - Sewing Pattern #2583

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: knit fusible interfacing, 4 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment - 2.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Yoke - cut 2
4. Placket - cut 4
5. Neckline facing - cut 2
6. Cuff - cut 2

Fusible interfacing:

1. Neckline facing – cut 1
2. Placket – cut 2
3. Cuff – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew a gathering stitch between the marks along the upper shoulder edge of the front piece and gather fullness. Sew yoke to front, press seam allowances towards top and serge. Sew shoulder seam, press seam allowances towards back and serge.
3. Pin plackets together, right sides together and sew the outer edge, clip seam allowances, turn right side out, straighten, press. Sew the outer placket to the right side of the front piece. Fold inside seam allowance of inner placket and stitch-in-the-ditch along seam of outer placket.
4. Pin neckline facings together, right sides together and sew the outer edge. Clip seam allowances, turn facing right side out, straighten, press. Sew the outer edge of the neckline facing into neckline, press the seam allowances towards the facing. Fold under the seam allowance along the inner side of facing and stitch-in-the-ditch along seam of outer side.
5. Fold cuff in half lengthwise, right sides together and press. Pin the cuff onto the wrong side of sleeve and sew. Fold the cuff onto the one-piece sleeve, sew seam allowances under the armhole together by hand and press.
6. Sew side seam, and continue sewing the sleeve seam, fastening the cuffs. Sew the cuff by hand to the shoulder seam and to the yoke.
7. Serge lower edge of garment, press onto wrong side and topstitch.
8. Make buttonholes and sew on buttons.

TECHNICAL DRAWING:

