

Shirt With Asymmetrical Front - Sewing Pattern #2587

Recommendations on fabric: natural/mixed fabrics suitable for shirts.

You will also need: fusible interfacing, 5 buttons, elastic tape, its width should equal 3.5 cm.

Seam allowances: all seams 1 cm. Seam allowance along the lower edge of front - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Attention! Pattern blocks have markings and texts from the right side. Take this into account when cutting the fabric-some of the pattern blocks need to be laid onto fabric with their wrong side on top.

Main fabric:

1. Back — cut 1 on fold
2. Front right - cut 1
3. Front left - cut 1

4. Sleeve - cut 2
5. Side - cut 4
6. Collar - cut 1
7. Cuff - cut 2

Fusible interfacing:

1. Collar - cut 1
2. Cuff - cut 2

INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusible interfacing to the one-piece placket.
2. Sew darts on back. Press bulk towards center.
3. Pin the side pieces together pairwise, right sides together, insert the front piece in between them, and sew the princess seam. Clip seam allowances, straighten the pieces. Sew a decorative stitch at 0.5 cm from seam.
4. Sew dart on front. Serge and press towards top.
5. Sew shoulder seams. Serge seams and press towards back. Sew in sleeves. Press the seam allowances towards the main piece, serge.
6. Fold collar in half lengthwise right sides together and sew short sides. Trim away corners, turn collar right side out and press.
7. Fold the seam allowance of the one-piece placket onto wrong side and press. Sew collar into neckline, wrapping the collar with the one-piece placket. Straighten pieces. Serge. Sew a decorative stitch along the placket.
8. Serge the seam allowances of the back and of the front. Fold inside the seam allowance of the back and topstitch. Sew side seams and sleeve seams, wrapping the lower edge of the back with the seam allowance of the front. Serge seams and press towards back. Sew a decorative/fixing stitch along the lower edge of the front.
9. Sew cuff into a ring. Press the seam allowances apart. Fold cuff in half lengthwise and press. Insert the elastic tape into the cuff, adjust its length and fix it with vertical stitch lines according to the markings.
10. Sew the cuff to the sleeve. Serge.
11. Make buttonholes on right placket, sew on the buttons on the left placket.

TECHNICAL DRAWING:

