

Jacket With Decorative Collar - Sewing Pattern #2601

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads; 4 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Center front - cut 2
5. Center front piece - cut 2
6. Sleeve - cut 2
7. Center front facing - cut 2

8. Back neck facing – cut 1
9. Collar – cut 2 on fold

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center front – cut 2
5. Sleeve – cut 2

Attention: The front piece and the back piece from lining fabric are cut using the sewing patterns for the main fabric, except for the width of the back neckline facing and the center front facing correspondingly.

Fusible interfacing:

1. Center front – cut 2
2. Center front piece – cut 2
3. Center front facing – cut 2
4. Back neck facing – cut 1
5. Collar – cut 1 on fold

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew side backs to center back, press the seam apart. Sew the center back seam, press the seam apart.
3. Pin together collars right sides together and sew along the edges. Trim seam allowances, turn right side out and press.
4. Sew side fronts to front, press the seam apart.
5. Sew and press apart shoulder edges. Sew the collar into the neckline of the front and into the neckline of the back. Sew the straight area of the collar to the central front, making pleats as desired.
6. Sew the center front piece to center front. Press towards center.
7. Sew side seams. Press the seam apart.
8. Sew side seams of back neckline facing and central front facings, press seam apart. Pin the central front facings and the facings onto front, right sides together, pin together and sew the center front edge, the neckline and the lower center front corner. Trim away corners, clip into curves. Topstitch the central front seam allowance onto center front facing. Place stitch line at 0,2 cm from seam. Turn center front facings right side out onto right side, straighten seams. Press lower edge of garment.

9. Press the hem of sleeve. Fold away seam allowance on hem, sew and press the sleeve seam apart.
10. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.
11. Sew seams on lining and sew in sleeves, leaving an opening for turning in left elbow seam. Sew lining to inner edges of the central front facings and to back neckline facing.
12. Sew lining to lower edge of garment and lower edge of sleeve. Turn jacket right side out. Sew the opening closed.
13. Make buttonholes and sew on buttons.

TECHNICAL DRAWING:

