

Short Coat - Sewing Pattern #2615

Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: lining, fusible interfacing; 8 sew-on push buttons; shoulder pads.

Seam allowances: all seams 1 cm. Seam allowance for hem of coat and hem of sleeve - 3.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Front - cut 2
3. Front side - cut 2
4. Sleeve - cut 2
5. Collar - cut 2
6. Center front facing - cut 2
7. Back neck facing - cut 1

8. Pocket - cut 2

Lining:

1. Back - cut 2
2. Front lining - cut 2
3. Sleeve - cut 2
4. Pocket lining - cut 2

Fusible interfacing:

1. Center front facing - cut 2
2. Back neck facing - cut 1
3. Collar - cut 1

The lining for back and for front is cut using the pattern pieces for the main fabric except for the width of the back neckline facing and of the center front facing.

INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusible interfacing to the one-piece facing of pocket. Apply fusible interfacing to the seam allowance for hem of sleeve.
2. Sew center back seam. Press the seam apart.
3. Sew darts on front. Cut away the bulk of the dart to 1 cm. Slash the seam allowance of the dart angle, gradually reducing the seam allowance remaining. Press the seam apart.
4. Sew the pocket lining to the one-piece pocket facing, press seam allowance at lining. Press pocket along the marked line and press. Pin pocket at front side and baste together along the princess seam edge, along the lower edge and along the side edge.
5. Sew side front to front, clip into seam allowance on front in corner. Press the seam apart.
6. Sew shoulder and side seams, press the seam apart. Sew in the outer collar into the front neckline and the back neckline. Press the seam apart.
7. Sew sleeve seam. Press the seam allowances apart. Press seam allowance for hem of sleeve onto wrong side. Sew sleeve into armhole. Press seam. Sew on shoulder pads.
8. Sew and press apart the shoulder edges of the back neckline facing and of the center front facing. Sew the inner collar into the neckline of the center front facing and into the neckline of facing, press the seam apart.
9. Turn under the lower edge of the coat, and press. Place center front facing onto front right sides together, pin together and sew center front edge and collar. Clip into seam allowances in corners. Turn center front

facings right side out, straighten seams, press. Sew together the seam allowances of the collars.

10. Sew seams on lining, leaving an opening in the seam of the left sleeve for turning the garment onto right side later. Sew lining to center front facings, to facing, to the hem of garment, and to the hem of sleeve. Turn coat right side out onto right side, sew the opening closed.

11. Sew on the push buttons according to the markings.

TECHNICAL DRAWING:

