

## Coat With Decorative Cuff - Sewing Pattern #2618

Recommendations on fabric: thin natural/mixed fabric suitable for coats.

You will also need: fusible interfacing; lining; shoulder pads; 6 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment - 3.5 cm, seam allowances along the side edges of the pocket welt, of the underlay piece and of the pocket bags - 2 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Back neck facing - cut 1
4. Center front facing - cut 2
5. Sleeve - cut 2
6. Collar - cut 2

7. Pocket welt - cut 2
8. Underlay piece - cut 2
9. Cuff - cut 4

Lining:

1. Back - cut 1 on fold
2. Front - cut 2
3. Sleeve - cut 2
4. Large pocket bag - cut 2
5. Small pocket bag - cut 2

Attention: The front and the back from lining fabric are cut using the pattern pieces for the main fabric except for the width of the center front facing and the neckline facing.

Fusible interfacing:

1. Center front facing - cut 2
2. Collar - cut 1
3. Pocket welt - cut 2
4. Underlay piece - cut 2
5. Cuff - cut 2

## **INSTRUCTIONS:**

1. Apply fusible interfacing.
2. Fold the pocket welt in half, wrong sides together, and press. Apply fusible interfacing to the pocket opening area. Mark the line on the off-set welt, that shows its width when ready. Topstitch small pocket bag onto inner side of welt. Pin the pocket welt onto the right side of front next to the marking line, the pocket welt is closer to center front. Sew off-set welt. Topstitch underlay piece onto bigger pocket bag, folding long edge under. Sew the bigger pocket bag to the other marking line of the pocket. Slash a pocket opening between the marked lines, making slashed cuts towards the corners of the marked pocket. Turn the pocket pieces onto the wrong side. Straighten seam allowances and press. Sew together edges of pocket bags, fixing corners of pocket.
3. Sew side and shoulder seams, press the seam apart. Serge the seam allowances of the side seams from the bottom up to waist.
4. Pin collars together, right sides together, and sew collar ends and collar fall. Trim away corners, clip into curves, turn collar right side out and press. Sew collar into neckline.
5. Sew sleeve seam, press the seam apart. Sew sleeves into armholes, adjusting ease on the sleeve in the upper part of the sleeve cap and matching notches. Sew shoulder pads.
6. Pin cuffs together, right sides together and sew along the lower edge and the side edges. Trim away corners,

clip into curves, turn cuff right side out and press. Place the front corner of the cuff onto the back corner of the cuff, and sew the cuff to the sleeve.

7. Sew shoulder seams of back neckline facing and central front facing, press the seam apart.

8. Sew together pieces of lining in the same way as you have sewn pieces from main fabric. Fold the seam allowance of the hem on lining two times by 1 cm and topstitch. Sew the lining to the front central facings and to the back facing. Press towards center front facing and serge.

9. Fold the seam allowance along the hem onto wrong side and press. Pin center front facing onto front right sides together, pin together and sew along center front edge and back neckline. Sew lower edges of central front facings to front exactly according to the marked line of hem. Trim the seam allowances of the lower corners along center front. Turn the coat right side out, straighten seams. Sew a decorative stitch at 0.7 cm from the edge center front facings and of collar.

10. Sew lining to hem of sleeve. Turn coat right side out onto right side.

11. Make buttonholes on right front, sew on buttons onto left front. Sew on buttons onto cuffs.

## **TECHNICAL DRAWING:**

