

Jacket With Peplum - Sewing Pattern #2671

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: lining; fusible interfacing; shoulder pads; 6 buttons; decorative tape (approximate length is given on the front pattern piece).

Seam allowances: all seams 1 cm. Seam allowance along hem of jacket and hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Upper back - cut 2
2. Lower back - cut 1 on fold
3. Upper front - cut 2
4. Lower front - cut 2
5. Sleeve - cut 2
6. Stand collar - cut 2

7. Back neck facing – cut 1
8. Center front facing – cut 2

Lining:

1. Upper back – cut 2
2. Lower back – cut 1 on fold
3. Upper front – cut 2
4. Lower front – cut 2
5. Sleeve – cut 2

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Stand collar – cut 1

Attention! Cut Back and Front from lining using the corresponding pieces for main fabric except for the width of back neckline facing and front neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back, shorten the bulk of the darts and press towards center. Sew the center back seam. Press the seam apart.
3. Sew a gathering stitch along the upper edge of lower back and gather fullness. Sew upper back to lower back. Press seam allowance towards top.
4. Sew darts on front, shorten the bulk of the darts and press towards center. Mark the position of the buttons on the left front. Topstitch the decorative band along the center line.
5. Sew a gathering stitch along the upper edge of lower front and gather fullness. Sew upper front to lower front. Press seam allowance towards top.
6. Sew shoulder and side seams, press the seam apart.
7. Pin together parts of stand collar, right sides together and sew along the upper edge. Clip into seam allowances on curves, turn stand collar right side out, straighten, press. Sew the stand collar into neckline.
8. Sew side seams of back neckline facing and central front facings, press seam apart. Pin the central front facings and the facings onto front, right sides together, pin together and sew the center front edge, the neckline and the lower center front corner. Trim away corners. Topstitch the central front seam allowance onto

center front facing. Place stitch line at 0,2 cm from seam. Turn center front facings right side out onto right side, straighten seams. Press lower edge of garment.

9. Sew sleeve seam, press the seam apart. Sew sleeves into armholes matching notches, press seam. Sew shoulder pads.

10. Sew together pieces of lining in the same way as you have sewn pieces from main fabric, leaving an opening in the left sleeve seam. Sew lining to center front facings and to facings, press seam allowances at center front facing. Sew lining to lower edge of garment and lower edge of sleeve. Turn jacket right side out. Sew the opening closed.

11. Make buttonholes on right front, sew on buttons onto left front.

TECHNICAL DRAWING:

