

T-Shirt With Yoke - Sewing Pattern #2677

Recommendations on fabric: soft natural/mixed knit fabric of medium stretchiness.

You will also need: knit fusible interfacing.

Seam allowances: all seams 1.0 cm; seam allowance along the hem of garment and hem of sleeve 2 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

Note on working with stretchy fabric:

Knitted fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hems can be stitched with twin needles to save stretchiness. Pieces can also be sewn together with a serger. When serging, cut seam allowances to 0.6 – 0.8 cm.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 1 on fold

3. Yoke - cut 2
4. Placket - cut 2
5. Sleeve - cut 2
6. Back neck facing - cut 1

Fusible interfacing:

1. Placket - cut 2
2. Back neck facing - cut 1

INSTRUCTIONS:

1. Fold the plackets in half lengthwise, wrong sides together. Pin the corner of the right placket onto the corner of the left placket and baste the pieces together along the lower edge.
2. Fold the yoke in half lengthwise, wrong sides together and press the fold. Baste together the sides of yoke along the armhole edge.
3. Sew yokes to front, inserting the plackets and clipping into seam allowance near corner. Serge, press towards bottom. Sew a decorative stitch along the seam at 0.5 cm.
4. Serge outer edge of back neckline facing. Pin neckline facing onto Back and sew neckline exactly up to the marked line of shoulder seam. Clip seam allowances, fold facing onto wrong side and press.
5. Sew shoulder seams, inserting the Front between the Back and the Facing, press towards the back and serge.
6. Sew side seams, press seam allowances towards back and serge.
7. Sew sleeve seam, press towards the back and serge. Sew sleeves into armholes, matching notches, serge and press.
8. Serge the seam allowances for hem of garment and hem of sleeve, fold inside onto wrong side and topstitch.

TECHNICAL DRAWING:

