

Jacket - Cape - Sewing Pattern #2681

Recommendations on fabric: natural/mixed stable fabrics.
(neoprene)

Seam allowances: all seams 1 cm. Seam allowance along hem and along center front edge - 0 cm. Seam allowance along the lower edge of the armhole, seam allowances of the sleeve EXCEPT for the upper part of the sleeve cap - 0 cm. Outer seam allowances of collar - 0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Pattern blocks have markings and texts from the right side. Take this into account when cutting the fabric-some of the pattern blocks need to be laid onto fabric with their wrong side on top.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Sleeve - cut 2

4. Collar - cut 1

INSTRUCTIONS:

1. Trim away the seam allowances of the neckline and of the lapel on the RIGHT front.
2. Sew side and shoulder seams. Trim seam allowances to 0.5 and press apart.
3. Pin the right front onto the right part of collar and topstitch along the marked line. Clip into corner of seam allowance.
4. Snip into seam allowances of the collar according to the markings. Sew in the collar into the back neckline, shorten the seam allowance leaving 0.5 cm and press apart. Sew collar into neckline of left front, the pieces should be pinned together wrong sides together. The seam allowances are thus placed on the right side of the garment. Trim seam allowances to 0.5 cm and press apart.
5. Sew in sleeve into the upper part of the armhole. Seam Allowance press.

TECHNICAL DRAWING:

