

Corduroy Jacket - Sewing Pattern #2689

Recommendations on fabric: soft suiting fabrics, natural/mixed corduroy fabrics.

You will also need: fusible interfacing; 9 buttons.

Seam allowances: all seams - 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Pattern blocks have markings and texts from the right side. Take this into account when cutting the fabric-some of the pattern blocks need to be laid onto fabric with their wrong side on top!

Main fabric:

1. Center back - cut 1 on fold
2. Side back - cut 2
3. Back yoke - cut 1
4. Front yoke - cut 2

5. Center front – cut 2
6. Center 2 front – cut 2
7. Side front – cut 2
8. Front sleeve – cut 2
9. Back sleeve – cut 2
10. Collar – cut 2
11. Cuff – cut 2
12. Pocket welt – cut 2
13. Flap – cut 4
14. Placket – cut 1 on fold
15. Large pocket bag – cut 2
16. Small pocket bag – cut 2

Fusible interfacing:

1. Collar – cut 1
2. Cuff – cut 2
3. Flap – cut 2
4. Pocket welt – cut 2
5. Placket – cut 1 on fold

INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusible interfacing to the one-piece placket on the front.
2. Sew side backs to center back. Serge seams and press towards center. Sew a decorative stitch at 0.5 cm from seam. Sew back yoke to yoke. Serge and press towards top.
3. Pin the pocket flaps together pairwise, right sides together and sew side and lower edges. Trim seam allowances, turn right side out and press. Sew a decorative stitch along the lower edge and the side edges.
4. Sew side fronts to front. Serge the seam allowances and press the seam allowances away from the central piece. Sew a decorative stitchline at 0.5 cm from the seams. Sew a decorative stitch, imitating a pocket. Sew front yoke to front, inserting flap. Serge seams and press towards top. Sew a decorative stitch at 0.5 cm from seam.
5. Mark the position of pocket. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew together edges of pocket bags.
6. Sew side and shoulder seams, press towards the back and serge.

7. Fold the one-piece placket on the front onto the wrong side. Sew the upper corner up to the center line. Cut the seam allowance in the corner. Snip into the seam allowance near the center line. Turn right side out and press center front edge. Turn under the longer seam allowance of the placket and topstitch.
8. Pin upper collar to lower collar, right sides together. Sew ends of collar and collar fall. Trim seam allowances. Turn the collar right side out, straighten and press. Sew a decorative stitch along the collar ends and the collar outer edge.
9. Sew the upper collar into the neckline of the garment. Fold the seam allowance of the lower collar onto wrong side and topstitch into the seam of the upper collar.
10. Snip into the seam allowance near the mark at the front sleeve. Serge the seam allowance of the slit. Sew front sleeve to back sleeve from the top up to the mark for the slit. Serge the seam allowances and press towards back. Sew a decorative stitch along the back sleeve at 0.5 cm from the seam. Sew a fixing stitch along the slit at the front sleeve.
11. Sew sleeve seam, press towards the back and serge.
12. Sew sleeves into armholes, serge and press. Sew a gathering stitch along the lower edge of the sleeve and gather fullness at the back part of the sleeve.
13. Fold cuffs in half lengthwise right sides together and sew side edges and corner. Start and stop stitching exactly at the marked line of the cuff seam. Turn the piece right side out, press. Sew the outer part of the cuff to the sleeve, fold inside the inner side of the cuff, and topstitch into the seam of the outer cuff cuffs.
14. Fold the lower placket in half lengthwise right sides together and sew side edges. Start and stop stitching exactly at the marked seam line plackets. Turn the piece right side out, press. Sew the outer side of the placket to the hem of garment, turn seam allowance of inner side of placket under and stitch-in-the-ditch along seam of outer placket. Sew decorative stitches along all the edges of the placket.
15. Make button holes on the right front, on the cuffs, and on the pocket flaps. Sew on buttons onto left front, pockets and cuffs.

TECHNICAL DRAWING:

