

Jacket With Slanted Closure - Sewing Pattern #2682

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads; 6 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Lower back - cut 1
4. Front - cut 2
5. Lower front - cut 2
6. Collar — cut 2
7. Center front facing — cut 2

8. Back neck facing – cut 1
9. Upper sleeve – cut 2
10. Lower sleeve – cut 2

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Lower back – cut 1
4. Front – cut 2
5. Lower front – cut 2
6. Upper sleeve – cut 2
7. Lower sleeve – cut 2

Lining is cut using pattern blocks for main fabric, except for the width of back neckline facing and central front facings.

Fusible interfacing:

1. Front – cut 2
2. Lower front – cut 2
3. Collar — cut 1
4. Center front facing — cut 2
5. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew side backs to center back, press towards center. Sew the center back seam, press the seam apart. Sew upper back to lower back, seam allowances press towards bottom.
3. Sew darts on front, cut away the bulk of the dart leaving 1 cm and press towards center. Sew upper front to lower front, seam allowances press towards bottom.
4. Sew the shoulder seams and the side seams of the garment, press the seam apart.
5. Pin collars together, right sides together, and sew collar ends and collar fall. Clip into curves, trim away corners. Turn collar right side out, straighten, press. Sew collar into neckline.
6. Sew side seams of center front facings and back neckline facings, press the seam apart. Pin center front facings onto garment right sides together and sew center front facings, neckline edge (the collar is placed between the facing and the garment) and the lower corner of the front piece. Clip into curves, trim away corners, turn pieces right side out, press.

7. Sew elbow seam on sleeve, press the seam apart. Press the hem of sleeve. Sew and press apart front sleeve seam. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.
8. Sew together pieces of lining in the same way as you have sewn pieces from main fabric, leaving an opening in left elbow seam of sleeve. Sew lining to facing and to central front facings. Turn garment right side out, straighten seams.
9. Mark the hem, fold inside and press. Sew lining to the hem of the garment and to the hem of the sleeve. Sew the opening closed.
10. Sew a decorative stitch along the upper part of the center front edge according to the markings. Make buttonholes on right front, sew on buttons onto left front. Make the upper button hole and the lower button hole on the left front, sew on the inner buttons on the right front.

TECHNICAL DRAWING:

