

Sewing Pattern — Dress 5946

Recommendations on fabric: dress fabrics of natural or mixed fibers

You will also need: blind zipper; fusing

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance : on hem of the dress and hem of sleeve – 3.0 cm, on neckline edge of central part front part – 2 cm, along slit of central part front part – 1.5 cm, along vent - 6 cm, all other seams - 1 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Back part - 2 details
2. Side back part - 2 details
3. Central front part – 2 details
4. Side front part - 2 details
5. Sleeve - 2 details
6. Facing of back part - 2 details

Fusing: Back neckline facing 2 details, seam allowance along neckline of front part, vent

INSTRUCTIONS:

1. Sew shoulder darts on back part. Press darts towards detail's center.
2. Cut 5 cm off on left central back part along vertical vent edge. Apply fusing on vent on both details of central back part from wrong sides. Mark middle seam line on right side (vent fold line). Press left part along vent fold line, on right part press only vent right side seam allowance (6 cm) onto wrong side. Align details along middle seam and fix on top vent edge. Serge middle edge of back part separately on every detail, serging the vent simultaneously. Sew middle edge of back part from zipper marker till vent edge. Slash corner seam allowance of vent on right part. Press seam allowances of middle seam apart, press seam allowances of the vent and fix them with machine stitch. Sew in blind zipper from top edge till notches.
3. Sew relieve seams on back part and of front part, press seam towards center and serge.

4. Apply fusing to seam allowance on neckline edge of front part. Slash seam allowance on front part near slit marks, serge and press neckline edge and slit section. Undersew seam allowance along slit with blind stitches or tack with fusing cobweb. Sew middle seam of front part. Press and serge seam.
5. Apply fusing to neckline facings of back part. Serge outer edge of the facings. Fold facings with back part neckline right sides together. Turn the facing 5 off blind zipper edges and fix to top edge of the dress. Turn seam allowances along zipper on right side of the dress and fix to neckline edge on top facings. Overstitch edge neckline. Slash seam on rounded parts, turn and press details. Turn seam allowances along zipper on wrong side and tack to zipper braid.
6. Sew shoulder seams of back part and of front part, inserting front part between details of back part and facings. Serge, turn and press towards back part.
7. Cut a strap of 8*10 cm size. Fold in half lengthwise wrong sides together, to get a strip of 4*10 cm size. Sew along long side. Turn and press the detail, placing seam in the center. Sew strap into ring, serge and topstitch.
8. Put upper edge of the dress trough the trap. Move the strap, sew upper edge of the dress. Serge and press. Put the strap in the center top edge and fasten.
9. Sew side seams. Press seams to back part and serge.
10. Sew edge of sleeve. Press and serge seam . Sew sleeves in armholes, aligning notches. Press and serge seam.
11. Press hem of the dress and hem of sleeve onto wrong side, serge and undersew with invisible stitches.

TECHNICAL DRAWING:

