

Shirt With Asymmetrical Front - Sewing Pattern #2837

Recommendations on fabric: natural/mixed fabrics suitable for shirts.

You will also need: fusible interfacing; 5 buttons.

Seam allowances: Seam allowance for hem of back - 2 cm; other seams - 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front right - cut 1
3. Front left - cut 1
4. Center Front Edge right - cut 2
5. Center Front Edge left - cut 2
6. Sleeve - cut 2
7. Collar - cut 2

8. Cuff - cut 2

Fusible interfacing:

1. Collar — cut 1
2. Cuff - cut 2
3. Center Front Edge right - cut 1
4. Center Front Edge left - cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Pin the right center fronts together, right sides together and sew along the outer edges. Clip seam allowances, trim away corners. Turn pieces right side out and press. Snip into seam allowance of the neckline near the mark. Sew a decorative stitch at 0.5 cm from seam.
3. Sew right center front edge to right front. Serge the seam allowances and press towards the main piece. Sew a decorative stitch at 0.5 cm from seam.
4. Sew the left front in the same way.
5. Sew shoulder seams, press towards the back and serge.
6. Pin upper collar to lower collar, right sides together, sew ends of collar and collar fall. Start and stop sewing exactly at the marked line of the seam between collar and garment. Trim seam allowances, turn the collar right side out, straighten and press. Sew a decorative stitch along the collar ends and the collar outer edge of collar. Turn finished collar right side out and press. Sew upper collar into neckline. Fold under the seam allowance of the lower collar and stitch-in-the-ditch into the seam of the upper collar.
7. Sew sleeves into armholes, serge and press.
8. Sew side seams and sleeve seams (the back is longer than the front by the width of the lower seam allowance). Serge seams and press towards back.
9. Fold cuffs in half lengthwise right sides together and sew side edges. Turn the piece right side out, press. Clip seam allowance for hem of sleeve near notch. Sew cuff to lower edge of sleeve, serge and press towards top. Sew a decorative stitch around all edges cuffs.
10. Serge lower seam allowance on back, turn inside and topstitch.
11. Make buttonholes and sew on buttons.

TECHNICAL DRAWING:

