

Jacket With Gathered Peplum - Sewing Pattern #2850

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; shoulder pads; 4 hooks and eyes.

Seam allowances: all seams 1 cm. Seam allowance along the hem of the jacket - 2 cm. Seam allowance on lower edge of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Upper back - cut 2
2. Lower back - cut 1 on fold
3. Front - cut 2
4. Placket - cut 1
5. Upper sleeve - cut 2
6. Lower sleeve - cut 2
7. Stand collar - cut 2

8. Back neck facing – cut 1
9. Center front facing – cut 2

Fusible interfacing:

1. Placket – cut 1
2. Center front facing – cut 2
3. Back neck facing – cut 1
4. Stand collar – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back, shorten the bulk of the darts to 1 cm, press towards center and serge. Sew the center back seam, press towards left and serge.
3. Sew a gathering stitch along the upper edge of lower back and gather fullness. Sew upper back to lower back, press towards top and serge.
4. Cut away the bulk of the darts on fronts, leaving 1 cm. Sew darts, press bulk towards center, serge.
5. Sew a gathering stitch along the upper edge of the 1-piece peplum on the front and gather fullness. Sew upper front to lower front, press towards top, serge.
6. Sew shoulder and side seams, press towards the back, serge.
7. Pin together parts of stand collar, right sides together and sew the ends and the upper edge. Trim away corners, clip into curves, turn stand collar right side out, straighten, press. Sew the stand collar into neckline.
8. Fold placket in half lengthwise right sides together and sew short sides. Turn right side out placket onto right side, straighten, press.
9. Sew side seams of back neckline facing and central front facings, press seam apart. Serge the outer edge. Pin center front facings onto the main piece right sides together and sew center front edge, neckline and lower edge, inserting the placket and the loops in between the left center front facing and the front. Trim away corners, clip into curves, fold center front facings and neckline facing onto wrong side, straighten, press. Sew the facing to the shoulder seams and to the center back seams by hand.
10. Sew the elbow seam and the front seam on the sleeve, press the seam allowances towards the upper part, serge. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap, serge and press. Sew shoulder pads.
11. Serge the seam allowances for hem of garment and hem of sleeve, fold inside onto wrong side and

topstitch.

12. Sew the hooks on the right front according to the eyelets.

TECHNICAL DRAWING:

