

## Poncho With Belt - Sewing Pattern #2879

Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: fusible interfacing; 1 button.

Seam allowances: all seams 1 cm; seam allowance for hem of garment - 3 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



## CUTTING:

### Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Front - cut 2
3. Center front facing - cut 2
4. Back neck facing - cut 1
5. Stand collar - cut 2
6. Belt - cut 1 on fold

Fusible interfacing:

1. Back neck facing – cut 1
2. Center front facing – cut 2
3. Stand collar – cut 1
4. Belt – cut 1 on fold

Tip: You can also use a ready belt.

## **INSTRUCTIONS:**

1. Apply fusible interfacing.
2. Sew the center back seam. Serge the seam allowances and press apart.
3. Make buttonholes for the belt.
4. Sew shoulder seams, sewing the sleeve edges at the same time. Serge seams and press towards back.
5. Pin together stand collars right sides together and sew collar ends and the outer edge of collar. Trim away corners, turn right side out and press.
6. Sew shoulder edges of center front facings and back neckline facing. Press the seam apart. Serge the outer edge. Pin the center front facings onto the garment, right sides together, adjust edges and sew center front facings and neckline, inserting collar. Clip seam allowances, straighten the pieces and press.
7. Serge bottom edge of garment and press onto wrong side. Sew the center front facing to the center front corner, trim away corner, turn right side out and press. Topstitch lower seam allowance.
8. Make a buttonhole on front and sew on a button.

## **TECHNICAL DRAWING:**

