

## Dress With Triangular Neckline - Sewing Pattern #2904

Recommendations on fabric: natural/mixed fabrics with elastane suitable for dresses.

You will also need: fusible interfacing; dress zipper; 2 buttons.

Seam allowances: all seams 1 cm; seam allowance for hem of dress — 2.5 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Center back - cut 2
2. Side back - cut 2.
3. Center front - cut 1 on fold
4. Side front - cut 2
5. Stand collar — cut 2
6. Front neckline facing — cut 2
7. Sleeve - cut 2

8. Cuff - cut 2

Fusible interfacing:

1. Stand collar — cut 1
2. Front neckline facing — cut 2
3. Cuff - cut 2

**INSTRUCTIONS:**

1. Apply fusible interfacing.
2. Sew side backs to center back, press towards center and serge.
3. Serge the center back edges separately. Serge the center back seam from neckline edge to the first marking and from the second marking down to hem, press the seam apart. Sew in zipper.
4. Serge the seam allowance of the integrated facing on the central front part, press it to the wrong side, and secure it along the princess seam edge.
5. Serge the outer edge facings decollette. Place the facing and the side front part together, insert the central front part between them, and sew the princess seams of the front. Serge seams and press towards center. Fold the facing onto the wrong side, straighten, press.
6. Sew shoulder seams, press towards the back and serge.
7. Pin together parts of stand collar, right sides together and sew upper and front edges. Start and stop stitching exactly at the marked sewing line. Clip into curves, trim away corners, turn stand collar right side out, straighten and press.
8. Place the outer stand collar and the garment right sides together and sew it to the front and back, matching the marks. Press the seam allowances toward the stand collar. Fold under the raw edge of the inner stand collar and stitch it into the seam of the outer stand collar.
9. Sew side seams, press towards the back and serge.
10. Sew a gathering stitch along lower edge of sleeve and gather fullness. Serge the sleeve edges separately. Sew sleeve seam from armhole up to mark for slit, press the seam apart. Topstitch slit at 0.1 cm from fold. Sew sleeves into armholes, serge and press.
11. Pin cuffs together, right sides together and sew side edges. Start and stop stitching exactly at the marked line of the cuff seam. Turn pieces right side out, straighten, press. Sew outer side of cuff to sleeve, fold inside the seam allowance of the inner cuff and topstitch into the seam of outer cuff.

12. Serge lower edge of garment, press onto wrong side and topstitch.

13. Make buttonholes on cuffs, sew on buttons.

**TECHNICAL DRAWING:**

