

Jacket With Decorative Fasteners - Sewing Pattern #2939

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: lining; fusible interfacing; 5 Asian-style frog closures; shoulder pads.

Seam allowances: Seam allowance for hem of garment and hem of sleeve – 3 cm; other seams – 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve — cut 2
7. Stand collar – cut 2

8. Center front facing – cut 2
9. Back neck facing – cut 1

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Stand collar – cut 1

Lining:

1. Center back - cut 2
2. Side back - cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve — cut 2

Attention! Lining is cut using pattern blocks for self fabric except for the width of center front facing and back neckline facing

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew side backs to center back, press the seam apart. Sew center back seam. Press the seam apart.
3. Sew side fronts to front. Press the seam apart.
4. Sew shoulder and side seams, press towards the back and serge.
5. Pin together parts of stand collar, right sides together and sew the ends and the upper edge. Trim away corners, clip into curves, turn stand collar right side out, straighten, press. Sew the stand collar into neckline.
6. Sew the elbow seam and the front seam on the sleeve, press the seam allowances towards the upper part, serge. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap, serge and press. Sew shoulder pads.
7. Sew side seams of back neckline facing and central front facings, press seam apart. Pin center front facings onto the main piece right sides together and sew center front edge, neckline and lower edge. Trim away corners, clip into curves, fold center front facings and neckline facing onto wrong side, straighten, press.
8. Press the jacket and sleeve hem allowances to the wrong side.
9. Sew seams on lining, leaving an opening in left elbow seam of sleeve. Sew lining to the central front facings

and to facing. Press the seam allowances towards the lining. Sew the lining to the jacket and sleeve hems.

10. Sew the facing to the shoulder seams and to the center back seams by hand. Turn jacket right side out through the opening. Sew the opening closed.

11. Sew the decorative fasteners onto the front pieces.

TECHNICAL DRAWING:

