

Sewing Pattern — Hoodie 5918

Recommendations on fabric: fleece / thick knit fabric

You will also need: fusing; cord for the hood (approximate length is mentioned on hood pattern); zipper (length is mentioned on front part pattern); bias tape of 4 cm wide; caps for cord.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: hem of the garment and of sleeve – 2 cm, outer edge of the hood - 2 cm, hem of buttonstand – 0 cm, pocket opening – 2 cm, all other seams - 1 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Main fabric:

1. Front part – 2 details
2. Back part - 1 detail
3. Sleeve - 2 details
4. Pocket – 2 details
5. Hood – 2 details
6. Front stand – 2 details

Advice:

Knitted fabric details are sewn together with special elastic or narrow zig-zag stitch. When serging cut seam allowances to 0.6 – 0.8 cm. Seam allowance on turnup is stitched with twin needles to save stretchiness.

INSTRUCTIONS:

1. Apply fusing to section on the hood where eyelets will be.
2. Serge pocket opening. Turn inside and topstitch. Serge and turn top, lower and side seam allowances of pockets onto wrong side and press. Mark pocket location on front part and topstitch the pocket.

3. Sew shoulder seams of the hoodie. Press seams towards back part and serge.
5. Sew in the zipper starting from the top and up to the notch for zipper.
6. Fold bias tape in half lengthwise wrong sides together and press. Fold details of the hood right sides together. Put bias tape onto edge of the hood and level edges. Sew details of the hood together with bias tape. Turn bias tape aside and topstitch it onto the hood, covering by that connecting seam of hood details. Make holes/eyelets. Serge outer edge of the hood, turn inside and topstitch onto wrong side. Cut eyelets through and run the cord through the carrier.
7. Serge outer and upper edge of the front stand.
8. Fold bias tape in half lengthwise wrong sides together and press. Fold details of the hoodie and the hood right sides together. Put front stand onto the hood with its right side inside. Put bias tape onto back part hood edge (bias tape should overlap the front part at 1.5 – 2 cm) and level edges. Sew details of the hood, the hoodie and front stand together with bias tape. Turn bias tape aside and topstitch it onto the hoodie, covering by that the hood connecting seam.
9. Fix upper edge of front stand along shoulder seam.
10. Sew sleeve into open armhole. Serge the seam. Sew side edge and edge of sleeve. Serge and press the seam onto back part.
11. Serge hem of the garment.
12. Turn inside hem seam allowance and topstitch.
13. Serge hem of sleeve, press onto wrong side and topstitch.

TECHNICAL DRAWING:

