

Sewing Pattern — Bolero 5911

Recommendations on fabric: jeans fabric

You will also need: 2 buttons

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: all seams - 1 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Front part - 2 details
2. Back part – 1 detail
3. Buttonstand – 2 details
4. Front part facing - 4 details
5. Back part facing – 2 details
6. Sleeve – 2 details
7. Cuff – 2 details

INSTRUCTIONS:

1. Make and press darts on front and back parts. Depths of darts are directed to shoulder edge, on back part - towards center. Sew darts. Stitch up darts at 2.5 cm from neckline and at 0.1 off the seam. Fix darts near neckline edge.
2. Sew shoulder seams. Press seams towards back part and serge.
3. Sew sleeve into open armhole. Serge seams and press onto the sleeve. Put decorative stitch along rounded part at 0.5 cm off the seam. Sew sleeve seam and side edge. Serge seam allowances and press towards back part.
4. Fold cuff right sides together and sew short edges. Turn out, straighten, fold in half lengthwise and press the cuffs. Stitch outer edge of cuff to lower edge of sleeve. Turn inside inner edge of cuff

at 1 cm and topstitch into outer edge connecting seam. Put decorative stitch along seam and along fold of cuff.

5. Sew side seams of front part and back part plackets. Press seams apart. Fold plackets right sides together and overstitch on lower and edge of buttonstand. Turn out, straighten and press the plackets. Stitch outer plackets to lower edges of front part and of back part. Turn inside open edge of inner placket at 1 cm and topstitch into outer placket connecting seam. Put decorative stitch along seam and along placket edge.

6. Fold plackets of front stand right sides together and overstitch along neckline edge and along two short edges. Turn, straighten and press plackets. Stitch upper plackets to neckline and buttonstand edge. Turn inside upper edge of lower placket at 1 cm and topstitch into upper placket connecting seam. Put decorative stitch along placket contour.

7. Serge buttonholes on right front part, sew buttons on left front part.

TECHNICAL DRAWING:

