

## Sewing Pattern — Bolero 5865

Recommendations on fabric: thick dress fabric.

You will also need: fusing.

Seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance 1 cm on all edges, on sleeve hem – 3 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Front part – 2 details.
2. Back part – 2 details.
3. Front facing – 2 details.
4. Back neckline facing – 1 detail.
5. Back hem facing – 1 detail.
6. Sleeve – 2 details.
7. Collar – 2 details.

Fusing:

1. Collar – 1 detail.

### **INSTRUCTIONS:**

1. Apply fusing to upper collar. Put together collar parts right sides together and overstitch on short edges and outer edge. Slash seam allowances on round parts, turn the right side out, press.
2. Sew darts on back part. Press dart depths towards back center. Sew middle back seam. Serge and press to the left.
3. Sew shoulder and side seams. Serge and press onto back part.
4. Sew shoulder seams of front facing and back neckline facing. Press the seams apart. Sew side seams of front facing and back hem facing. Press the seams apart. Serge inner edge of front facing, back neckline facing and back hem facing.
5. Put bolero and facings right sides together. Overstitch front edge, hem and neckline, inserting collar. Turn the right side out, adjust and press. Fix back facings onto side and

shoulder seams.

6. Sew sleeve seams. Serge and press to the back part. Sew sleeves into armholes. Serge the seam.

7. Serge sleeve hem. Fold seam allowance inside and topstitch.

**TECHNICAL DRAWING:**

