

Sewing Pattern — Dress 5862

Recommendations on fabric: dress fabrics of natural or mixed fibers.

You will also need: blind zipper, fusing, elastic yarn.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: hem of the dress – 2.0 cm, all other seams 1 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Back part - 2 details
2. Front part – 2 details
3. Facing of back part - 2 details
4. Facing of front part - 1 detail

Fusing:

1. Facing of back part - 2 details
2. Facing of front part - 1 detail

INSTRUCTIONS:

1. Sew darts on details of back part. Press darts towards center of the detail.
2. Make bow pleats on details of back and of front parts parallel to shoulder edge according to markers. Fix pleats along edges. Make and fasten pleats on front part low neckline.
3. Slash seam allowances in corners on front part near markers. Fold detail of front part right sides together, aligning curvilinear edges, and sew from marker up to the end of the edge. Press seam allowance and slash. Fold given tie so that seam is in the center and overstretch the straight edge. Cut seam allowance, turn the tie onto right side.
4. Fold front parts details together and sew top and lower center edges. Press apart seam allowances of top part, press seam allowances of lower part onto left side and serge.
5. Serge horizontal edges of front part and sew using the elastic yarn.

6. Serge center edge of back part. Sew in the zipper from top edge up to the notch. Turn lower part of the zipper away and sew center edge of back part from notch downwards. Press seam allowances apart.
7. Sew side and shoulder edges. Press apart allowances of shoulder seams, press allowances of side seams to back part and serge.
8. Apply fusing to back part / front part neckline facings. Sew shoulder and side edges, press seam allowances apart, serge lower edge of the facings. Overstitch the neckline of back part / front part. Slash seam on rounded parts, turn the facing out and press. Stitch center edge of the facing to zipper tape. Overstitch armhole in two steps: from shoulder seam up to side seam on side of back part and from shoulder seam up to side seam on side of front part.
9. Press hem of the dress onto wrong side, turn inside again at 1 cm and topstitch.

TECHNICAL DRAWING:

