

Sewing Pattern — Velvet blouse 5856

Recommendations on fabric: stretch velvet, crepe-chiffon

You will also need: bias tape

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: on back part and front part neckline edges – 1. 2 cm; along the edge of sleeve — 2 cm; all other seams - 1 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Velvet:

1. Back part – 1 detail
2. Front part – 1 detail
3. Sleeve – 2 details

Crepe-chiffon:

1. Upper flounce – 1 detail (parameters are shown on front part pattern)
2. Lower flounce – 1 detail (parameters are shown on front part pattern)

When cutting pay attention to pile direction. It must be directed upwards, exactly on all details. To avoid pile deformation, press seam allowances either on a piece of the same velvet, or on thick loop towel from the wrong side.

Advice:

Knitted fabric details are sewn together with special elastic or narrow zig-zag stitch. When serging cut seam allowances to 0.6 – 0.8 cm. Seam allowance on turnout is stitched with twin needles to save stretchiness. Details also can be sewn together via 3 or 4 – threaded serger.

INSTRUCTIONS:

1. Press top flounce in half lengthwise wrong sides together. Make evenly distributed plaits so that the lower edge length coincides with front part neckline length.
2. Press seam allowance of front part neckline onto wrong side. Put top flounce under it so that open edges coincide and topstitch.
3. Turn back part neckline seam allowance onto wrong side and topstitch.
4. Sew shoulder seams.
5. Stitch loosely on top edge of sleeve and gather ruffles. Pipe hem of sleeve with bias tape. Sew sleeve into open armhole.
6. Sew side edges and edges of sleeves with one seam.
7. Serge lower edge lower of the flounce with thin rolled seam. Sew lower flounce into ring. Make evenly distributed plaits on the flounce so that top edge length coincides with blouse lower edge length.
8. Press seam allowance of blouse lower edge onto wrong side. Put lower flounce under it so that open edges coincide and topstitch.
9. Overstitch two bows from bias tape and sew them to the sleeves.

TECHNICAL DRAWING:

