

## Sewing Pattern — Coat 5834

Recommendations on fabric: fabric suitable for coats.

You will also need: fusible interfacing; lining; raglan shoulder pads; 3 buttons.

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: all seams - 1 cm; on hem – 4 cm.

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



### **CUTTING:**

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

#### Fabric:

1. Back - cut 2
2. Front — cut 2
3. Side back — cut 2
4. Side front — cut 2
5. Collar – cut 2
6. Back neckline facing – cut 1
7. Front band facing – cut 2
8. Cuff – cut 2
9. Belt – cut 1

#### Lining:

1. Back - cut 2
2. Front — cut 2
3. Side back — cut 2
4. Side front — cut 2
5. Pocket sacking – cut 4

Fusible interfacing:

1. Front band facing – cut 2
2. Back neckline facing – cut 1
3. Collar – cut 1

**Note:** front and back details from lining are cut using main fabric pattern pieces, excluding the width of front band facings and back neckline facing respectively.

Note: serge princess seams and side seams on fabric and on lining from hem to waist.

**INSTRUCTIONS:**

1. Apply interfacing to listed pieces. Apply interfacing to pocket location on central and side fronts. Also apply interfacing on armhole on side front. Apply fusible tape of 1 cm wide from neckline to hem on fronts and backs. Fuse upper corner on armhole of front and back. Press cuffs in half lengthwise. Apply interfacing to half of cuff. Interfacing goes over fold-line at 1-2 cm.
2. Sew side and central backs. Serge seam allowances and press apart. Clip corner on back at the armhole beginning. Sew sections of lower part of armhole and curve on back. Press seam toward sleeve. Sew middle edge of back. Press seam apart and serge.
3. Sew pocket sackings to one-piece underlay pieces. Press seams to sacking. Sew side fronts to central fronts sewing pocket sackings at the same time. Slash seams at pocket entrance on side front. Press underlay pieces to center of front, press apart and serge side and central fronts connecting seam. Clip corner on front near armhole beginning. Sew sections of lower part of armhole and curve on front. Press seam toward armhole.
4. Sew upper sleeve edges. Press apart seams. Sew lower sleeve edges and side seams with one stitch. Press apart and serge seams. Fold cuffs into ring right sides together and stitch. Press apart the seam. Turn cuffs out, fold in half and press. Sew cuffs to sleeves with unfused side. Press apart the seam.
5. Place collars right sides together. Stitch from right side the end of collar from “o” mark to upper edge. Trim seam. Slash seam allowance at the mark near the seam beginning. Turn collar out and press. Sew upper collar into neckline. Press apart the seam.
6. Sew shoulder edges of back neckline facing and front band facing. Press apart the seam.
7. Place right front band facing on front, right sides together, and stitch **right** front band and lapel ledge. Topstitch seam allowance (from hem to notch) onto front band facing. Stitch at 0.2 cm from the seam. Sew lower edge of front band facing to front exactly on hem turnup line, leaving 1.5 cm to inner edge of front band facing. Trim seam of lower corner of front band. Slash neckline seam allowance near the ledge mark. Turn front band right side out, straighten seams. Sew lower collar into neckline of facing and front band facing. Press apart the seam.
8. Place left front band facing onto front right sides together and stitch left front band and collar. Topstitch seam allowance (from hem to notch) onto front band facing. Stitch at 0.2 cm from the seam. Sew lower edge of front band facing to front exactly on hem turnup line, leaving 1.5 cm to inner edge of front band facing. Trim seam of lower corner of front band. Press collar and front bands. Make a fastening stitch along collar and neckline connecting seam. Make a decorative stitch at 1 cm from the edge of front band, lapel and collar.
9. Sew details from lining the same way as main fabric details. Turn hem of lining twice inside at 1.5 cm and topstitch.
10. Serge and press hem turnup. Sew shoulder pads. Sew lining to inner edges of front band facings and back neckline facing. Start and end stitch at half width of main garment hem turnup. Slash seam allowance on inner edge of front band facing, near the beginning of lining connection. Turn inside seam allowance of front band facing from hem to slash line and slip-stitch. Serge lining connecting seam and press toward lining.

11. Sew lining to cuffs. Press seam on cuff. Make fastening stitch along cuff connecting seam.
12. Serge button holes on right front and collar, sew buttons on left front.
13. Fold belt in half lengthwise right side together and stitch one long and two short sides. Turn belt right side out, turn under seam allowance of unsewn section and make decorative stitch at 0.7 cm on belt perimeter.

**TECHNICAL DRAWING:**

