

Sewing Pattern — Dress 5826

Recommendations on fabric: natural or mixed fabric suitable for dresses

You will also need: blind zipper, lining

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: all seams - 1 cm, lower edge of skirt panels - 3 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Main fabric:

1. Central back part - 2 details
2. Side back part - 2 details
3. Side front part - 2 details
4. Central front part – 1 detail
5. Back skirt panel - 1 detail
6. Front skirt panel - 1 detail

Lining:

1. Central back part - 2 details
2. Side back part - 2 details
3. Side front part - 2 details
4. Central front part – 1 detail

INSTRUCTIONS:

1. Sew princess edges of front part and of back part, press seam allowances towards center and topstitch at 0.1 cm off the seam.
2. Serge center edge of back part. Sew in zipper from top edge up to the notch. Turn lower part of zipper and sew center edge of back part from notch downwards. Press seam allowances apart.
3. Sew side and shoulder edges, press seam allowances apart.

4. Sew details of lining the same way as main fabric details. Fold lining with main fabric right sides together and overstretch neckline edge and edges of armholes. Press seam allowances, slash on rounded parts. Turn bodice out, serge, press. Put decorative stitch along neckline and armholes at 0.2 cm off the seam. Turn seam allowances of center edge of back part from lining and fix to zipper tape. Fix lining to main fabric along the lower edge.
5. Slash seam allowances in corners near pleats on details of skirt panels and serge top and side sides of pleats. Fold longitudinal edges of pleats right sides together and sew, press seam allowances apart. Turn the pleat onto right side out and press, placing seam in the center. Press seam allowance of top edge of pleat inside.
6. Sew side edges of skirt panels, press towards back part and serge. Fold the skirt with bodice and sew, turning pleats away. Press seam allowances upwards and serge. Topstitch top turned edge of the pleat onto the bodice.
7. Press lower edge of the garment onto wrong side at turnup width, turn inside at 1 cm and topstitch.

TECHNICAL DRAWING:

