

Sewing Pattern — Top 5816

Recommendations on fabric: natural or mixed thin blouse fabric.

You will also need: using, bias tape, 2 buttons, elastic, elastic yarn

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: hem - 0 cm, along flounce contour - 0 cm, all other seams - 1 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Main fabric:

1. Back part – 1 detail
2. Front part – 2 details
3. Placket – 2 details
4. Strap – 2 details
5. Flounce – 1 detail
6. Lower part – 2 details

Fusing:

1. Placket – 1 detail

INSTRUCTIONS:

1. Apply fusing to upper placket.
2. Fold the strap in half lengthwise right sides together and overstitch on long side. Turn the strap out and press.
3. Sew the dart on front part. Press the dart upwards.
4. Cut the flounce in spiral. Overstitch outer edge of the flounce with bias tape. Measure off the length of the flounce on open edge. Its length is equal to front part center edge minus 1 cm.
5. Fold details of front part right sides together, insert flounce between them from the neckline and, leaving 1 cm to lower edge, level edges and sew center edge. Serge and press the seam.

6. Sew side seams. Serge seams and press towards back part. Serge edge of the armhole of front part and upper edge of back part. Press the cutoff onto wrong side. Put the elastic under the cutoff on back part between central notches, slightly stretching it. Topstitch the edge onto main detail. Stitch straps to back part. The fold of the straps is directed towards center of back part.
7. Fold details of the placket and overstitch along inner edge, overstitching side edges of the placket. Cut seam allowances. Turn the detail out and press. Press lower edges inside. Stitch straps and upper edge of front part to lower placket according to marking. Stitch upper placket into the edge to lower placket. Press details.
8. Sew side seams of lower parts. Serge the seam and press it towards back part. Put the stitches with elastic yarn according to markers. Stitch lower part to upper part. Serge the seam and press it upwards.
9. Overstitch hem of the garment with rolled seam.
10. Serge buttonholes on front part and sew buttons.

TECHNICAL DRAWING:

