

## Sewing Pattern — Hoodie 5755

Recommendations on fabric: natural/mixed fabric

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams. 3 cm for ferment/sleeve hems and for pocket lower edge.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Back part – 1 piece
2. Front part – 1 piece
3. Back sleeve – 2 pieces
4. Front sleeve – 2 pieces
5. Patch pocket – 1 piece
6. Hood – 4 pieces

### **INSTRUCTIONS:**

1. Stitch front darts, press depth upward.
2. Cut fabric non-straight stripe of 4 cm width and of length equal to front slit's double length. Press the stripe along the center, unfold it and press long edges toward marked line. Cut a slit into front part and trim it with this piping.
3. Neaten pocket's edges excluding the lower one. Press pocket entrance's edge into wrong side and topstitch with double stitch at 0.1 cm and 0.7 cm from edges. Press upper/side edges into

wrong side, lay the pocket on front part as marked and topstitch with double stitch at 0.1-0.7 cm from edges.

4. Stitch back sleeves to back part. Stitch front sleeves to front part. Press seam allowances and topstitch the seam.

5. Stitch sleeve upper edges. Press seam allowances apart. Stitch sleeve lower edges/side edges with one seam. Press seam allowances apart.

6. Stitch hoods in pairs. Inner hood: press joining seam leftward and topstitch with double stitch at 0.1-0.7 cm distance. Outerhood: press seam allowances apart. Lay hoods right sides together and overstretch along outer contour; begin and finish overstretching at the line of joining the hood. Turn the hood right side out and press the seam.

7. Stitch inner hood into the neckline, fold outer hood's lower open edge under and topstitch along joining seam. Make decorative stitch at 0.7 cm from hood edge.

8. Press garment/sleeve hems into wrong side, fold them under at 0.5 cm and topstitch them.

#### **TECHNICAL DRAWING:**

