

Sewing Pattern — Double-cloth jacket 5698

Recommendations on fabric: faux sheepskin (short/medium length coat)

You will also need: 3 toggle fasteners, appropriate adhesive glue for the fabric

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: 4.5 cm for all open edges (front edge, garment/sleeve hems, hood hem); 1.5 cm for other seams

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Fabric:

1. Side front – cut 2
2. Center front – cut 2
3. Back – cut 2
4. Hood front – cut 2
5. Hood back – cut 2
6. Sleeve – cut 2

INSTRUCTIONS:

1. Sew side front to center front with their right sides together. Lay seam allowances apart and glue with fabric adhesive.
2. Lay backs right sides together, sew center back seam. Lay seam allowances apart and glue with fabric adhesive.
3. Sew shoulder seams. Lay seam allowances apart and glue with fabric adhesive.
4. Sew sleeves into open armholes according to notches. Slash allowances, lay them apart and glue with fabric adhesive.

5. Sew side seam and sleeve seam with one continuous stitch. Lay seam allowances apart and glue with fabric adhesive.
6. Sew hood back to hood front. Lay seam allowances apart and glue with fabric adhesive. Sew hood along center line. Lay seam allowances apart and glue with fabric adhesive.
7. Sew the hood to the garment. Slash allowances, lay them apart and glue with fabric adhesive to the hood, and neckline allowance of front/back.
8. Turn front edge/sleeve hems/hem/hood allowances toward suede side, then topstitch.
9. Sew the toggle fasteners as marked.

TECHNICAL DRAWING:

