

Sewing Pattern — Blouse 4239

Recommendations on fabric: natural or mixed blouse fabric

You will also need: fusing; blind zipper

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: all seams - 1 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Main fabric:

1. Central front part - 1 folded detail
2. Central back part – 2 details
3. Sleeve - 2 details
4. Side front part - 2 details
5. Side back part - 2 details
6. Front basque – 1 detail
7. Back basque — 2 details
8. Flounce — 2 details
9. Back neckline facing — 2 details
10. Front neckline facing — 1 detail

INSTRUCTIONS:

1. Apply fusing to facings. Sew shoulder seams of the facings. Serge along outer contour of the facings.
2. Sew princess edges on front part and back part. Serge seams and press the seam towards center of front part and of back part correspondingly.
3. Serge center edge of back part.
4. Sew shoulder and side edges. Press seams to back part and serge.
5. Put facings onto right side of the blouse and overstretch the neckline. Slash seam allowances on rounded parts. Turn facings onto wrong side and press. Fix facings by hand at shoulder seams level.
6. Sew side seams of basques. Serge and press seam allowances to back part. Serge center edges of back basque. Stitch basque to lower edge of the blouse. Serge and press downwards. Sew section from marker downwards on basque detail. Sew zipper into center edge of back part. Press hem of the basque onto wrong side, serge and topstitch.

7. Sew sleeve seam. Serge seam allowance and press to back part. Sew sleeve into armhole, aligning notches. Sew sleeve flounce seam. Serge seam allowance and press to back part. Press hem of the flounce onto wrong side, serge and topstitch. Stitch sleeve flounce to the sleeve, aligning notches. Serge and press onto flounce.

TECHNICAL DRAWING:

