

Sewing Pattern — Top 5650

Recommendations on fabric: middle/high stretchable jersey (natural or mixed)

You will also need: separable zipper

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

SEAM ALLOWANCE: 1.5 cm for hem/sleeve hems, 1 cm for other seams

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.

CUTTING:

(On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.)

Advice:

Knit fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hem is stitched with twin needles to save stretchiness. Pieces can also be sewn together with 3 or 4 – thread serger. When serging, cut seam allowances to 0.6 – 0.8 cm.

Fabric 1:

1. Back part – 1 piece
2. Front part – 1 piece
3. Sleeve – 2 pieces
4. Collar – 1 piece
5. Front band – 2 pieces



INSTRUCTIONS:

1. Stitch shoulder edges of front/back parts. Neaten seams and press them backward.
2. Stitch outer collar into neckline coinciding notches.
3. Neaten front bands' outer edges.
4. Tack the zipper to front edgings. Lay front bands on front parts right sides together with the zipper between them. Stitch the zipper in. Fold front bands into wrong side and tack together along neckline edges. Stitch collar edge to the zipper. Fold collar's open edge under and topstitch along neckline seam. Make decorative stitch along front edgings.
5. Stitch side edges of front/back parts. Neaten seams and press them backward.
6. Stitch sleeve seams. Neaten seams and press them sidewise.
7. Stitch sleeves into armholes coinciding notches. Neaten seams and press them.
8. Neaten the hem and sleeve hems. Press edges into wrong side and topstitch. Fix front bands to front parts.

TECHNICAL DRAWING:

