

Sewing Pattern — Top 5624

Recommendations on fabric: sheer natural/mixed fabric

You will also need: concealed zip; fusing; 1 button; piping.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 0 cm for armholes, 1.5 cm for the hem, 1 cm for other seams

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Center back part – 2 pieces
2. Side back part – 2 pieces
3. Center front part – 1 piece
4. Side front part – 2 pieces
5. Collar – 2 pieces

Fusing:

1. Collar – 1 piece

INSTRUCTIONS:

1. Apply the fusing to wrong side of the collar.
2. Stitch front/back relieves. Neaten the seams and press them toward centers.
3. Stitch side seams. Neaten the seams and press them backward.
4. Neaten middle back edge. Stitch middle back seam up to the closure notch. Press middle seam apart, press closure slit. Stitch the zipper in.
5. Press the piping along the center and overstitch armholes.

6. Lay collars together. Overstitch inner collar with outer one, cut allowances and turn the collar right side out. Press the collar pressing lower edges.
7. Stitch the collar to front/back parts coinciding notches.
8. Neaten the hem and topstitch at 1.5 cm.
9. Make a loop into the collar and sew the button.

TECHNICAL DRAWING:

