

## Sewing Pattern — Top 5622

Recommendations on fabric: natural/mixed fabric

You will also need: concealed zip; fusing.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1.5 cm for the hem, 1 cm for other seams

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Center back part – 2 pieces
2. Side back part – 2 pieces
3. Center front part – 1 piece
4. Side front part – 2 pieces
5. Center front facing – 1 piece
6. Side front facing – 2 pieces
7. Back facing – 2 pieces

Fusing:

1. Back facing – 2 pieces
2. Center front facing – 1 piece
3. Side front facing – 2 pieces

### **INSTRUCTIONS:**

1. Apply the fusing to wrong side of back/center front/side front parts.
2. Overstitch the neckline with the piping. Turn the seam out and press.
3. Stitch back/side front facings together along side edges. Neaten the seam and press them apart. Neaten facings' lower edge.

4. Stitch back relieves. Neaten them and press toward the center. Stitch side edges together. Neaten seams and press them backward.
5. Neaten middle back edge. Stitch middle back seam up to closure notch. Press middle back seam apart pressing closure slits. Stitch the zipper in.
6. Stitch front relieves coinciding notches.
7. Stitch facings along collar middle line. Stitch side front parts along collar middle line. Neaten seams and press them.
8. Lay the facing on side front part right sides together. Overstitch collar fly and collar corners, then stitch the facing to front relieve seam. Slash seam allowance in the corner. Neaten the seam between the corner and the hem and press it sideward. Turn the collar right side out and press it.
9. Lay the facing on back part right sides together. Fold the facing at 5 mm before zipper's edges and pin to top's upper edge. Fold allowances along the zipper into right side and pin them to upper edge above the lining. Overstitch back part's upper edges. Fold closure allowances into wrong side. Fold the facing upward and topstitch on back part on seam allowance at 1-2 mm from the seam. Fold the facing into wrong side and fix to zipper braid. Press details.
10. Press front armholes'/collar allowances inside. Topstitch details one on another making stitches at 0.2 cm from edges.
11. Neaten the hem, fold it into wrong side and topstitch at 1.5 cm from lower edge.

**TECHNICAL DRAWING:**

