

## Sewing Pattern — Dress 4235

Recommendations on fabric: fabric suitable for dresses

You will also need: lace tape of 3 cm wide; blind zipper, fusing

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: on hem of the dress – 3.0 cm; along the vent – 6 cm; all other seams - 1 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Upper front part - 2 details
2. Lower front part - 1 detail
3. Back part - 2 details
4. Facing of back part - 2 details
5. Facing of front part – 1 detail

Fusing:

1. Facing of back part - 2 details
2. Facing of front part – 1 detail

### **INSTRUCTIONS:**

1. Apply fusing to details of the facings.
2. Sew darts on back part and front parts, press depths to center of corresponding details.
3. Cut off 5 cm on left part of the back along vertical edge of the vent. Apply fusing to the wrong side of the vent on both details of the back. Mark center seam line (vent foldline) on right side. Press left part along vent foldline, press only seam allowance of right side of the vent (6 cm) on right part onto wrong side. Align details according to center seam and fix on top edge of the vent. Serge center edge of back part separately on each detail. Serge seam allowances of the vent. Sew center edge of back part from closure marker up to vent corner. Slash corner of vent seam allowance on right part. Press apart seam allowances of the center seam, press seam allowances

of the vent and fix them on right side with machine stitch. Sew in the zipper.

4. Stitch upper part of the front to lower part, press seam allowances upwards and serge.

5. Sew side and shoulder edges, press seam onto back part and serge.

6. Sew side and shoulder edges of the facings, press seam allowances apart. Serge lower edge of the facings. Fold details of the facings with garment right sides touching and overstretch front part and back part neckline edge. Overstretch armhole in two steps: first armhole of back part, then armhole of front part. Topstitch seam allowance onto the facing by 0, 2 cm off the seam. Turn the facing onto wrong side and press. Stitch center edge of the facing to zipper allowance.

7. Serge hem of garment. Turn onto wrong side, press and undersew with invisible stitches.

8. Topstitch lace onto front part neckline.

### **TECHNICAL DRAWING:**

