

Sewing Pattern — Top 5613

Recommendations on fabric: silk/viscose

You will also need: fusible interfacing; decorative cord

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowances: 1 cm for all seams.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Fabric:

1. Front – cut 1
2. Back – cut 2
3. Front neck facing – cut 1
4. Back neck facing – cut 1
5. Front inset – cut 2
6. Back inset – cut 2
7. Lower back – cut 1
8. Lower front – cut 1

Fusible interfacing: front/back neck facing

INSTRUCTIONS:

1. Apply interfacing to wrong side of front/back neck facings.
2. Sew darts on upper front, press towards center.
3. Sew darts on upper back, press towards center.
4. Sew center back seam. Serge seam and press toward left.
5. Sew side seams and shoulder seams. Serge and press toward back.
6. Sew side seams of lower front and back. Serge and press toward back.
7. Sew side seams of front and back insets. Press seams apart.
8. Make a gathering stitch at 0.5 cm along upper edge of lower front/back. Gather fullness equally according to front/back inset lower edge (see length of lower front/back on patterns).
9. Make buttonholes on upper front inset. Serge lower edge of inner front/back insets. Sew front/back outer inset to upper edge of lower front/back. Sew upper front/back to inner/outer front/back insets so that upper part is between insets. Fold inner inset downwards and topstitch on the seam joining outer inset.
10. Sew facing shoulder seams. Serge outer edges of facing. Pin facing on the garment, right sides together, and sew front/back neckline. Understitch front/back neckline and press. Tack front/back neckline facing shoulder seams to blouse shoulder seams with 1 cm stitch.
11. Serge armholes, fold edges onto wrong side and topstitch.
12. Serge bottom edge of garment, fold onto wrong side, and topstitch. Pull the cord through insets and out through buttonholes.

TECHNICAL DRAWING:

