

Sewing Pattern — Hooded shirt 5606

Recommendations on fabric: natural fabric suitable for skirts

You will also need: fusing; 6 buttons; decorative cord; tabs

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowances: 1 cm for all seams, 2 cm for garment/sleeve hems allowance, 2 cm for hood outer edge

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Center back part – 1 piece
2. Side back part – 2 pieces
3. Center front part – 2 pieces
4. Side front part – 2 pieces
5. Hood – 2 pieces
6. Center hood part – 1 piece
7. Sleeve – 2 pieces
8. Front band – 2 pieces
9. Back neckline facing – 1 piece

Fusing: front band, back neckline facing

INSTRUCTIONS:

1. Apply the fusing to wrong side of front band, back neckline facing.
2. Stitch front relieve seams and neaten them. Press relieve seams towards front center. Stitch back relieve seams and neaten them. Press relieve seams towards back center.

3. Stitch facing/front band shoulder seams and press them apart. Neaten front/back neckline facing's inner edges.
4. Stitch shoulder/side edges. Neaten shoulder/side seams. Press shoulder/side seams backwards.
5. Stitch hood sides to hood center part and neaten seams. Make buttonholes into the hood. Fold hood outer allowance into wrong side, fold it under and topstitch on the hood.
6. Stitch the hood into neckline. Overstitch the neckline with facing and front bands. Overstitch front edgings with front bands, slash extra fabric in corners and turn front bands right side out. Press front bands. Fix facing and front bands with z stitch at shoulder seam.
7. Stitch sleeve edges. Neaten them and press backwards. Stitch sleeve in easing them along sleeve caps. Neaten joining seams.
8. Neaten shirt/sleeve hems, fold them under and topstitch.
9. Make buttonholes into right front edging, sew buttons on the left one.
10. Pull the cord into the hood and set tabs.

TECHNICAL DRAWING:

