

Sewing Pattern — Dress 4230

Recommendations on fabric: natural/mixed silk, well draping fabric

You will also need: 6 buttons; fusing; elastic of 1 cm wide

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: all seams -1 cm, hem of front / back parts – 2 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Upper back part – 1 detail
2. Lower back part – 1 detail
3. Side front part - 2 details
4. Center front part - 2 details
5. Lower front part – 1 detail
6. Stand-up part of collar – 2 details
7. Belt loop - 1 detail
8. Belt - 1 folded detail

Fusing: stand-up part of collar, one-piece placket

INSTRUCTIONS:

1. Apply fusing to stand-up part of collar and one-piece placket on central front part.
2. Make and stitch up pleats on central front part. Depths are turned towards side edge.
3. Press buttonstand edge on central front part onto wrong side at 1 cm. Turn one-piece placket along buttonstand line onto right side and overstitch top corner. Slash seam allowance near the notch, turn placket on wrong side, press. Topstitch the placket onto front part along inner fold.
4. Stitch side front part to central front part, slashing in corner, press seam allowances upwards and to side edge and serge.
5. Serge buttonholes on right placket, sew buttons on left placket. Put front parts one onto another, fix along the lower edge and sew then as one detail .

6. Sew shoulder seams, press seam onto back part and serge.
7. Fold stand-up parts of collar right sides together and overstitch outer edge. Start and finish the stitch near marked line of stand-up collar/the neckline connecting seam. Slash seam allowances, turn stand-up part of collar onto right side, press.
8. Sew outer stand-up part of collar into the neckline, turn inside unsewn longitudinal edge of inner stand-up part of collar and topstitch into connecting seam.
9. Cut bias tape of 4 cm wide and as long as the armhole + 5 cm. Fold bias tape in half lengthwise wrong sides together and press. Fold the bias tape with armhole edge from right side and stitch, slash seam allowances. Turn bias tape onto wrong side and topstitch along the fold onto main detail, press.
10. Sew side seams of upper part. Press seam allowances towards back part and serge.
11. Sew side seams of lower part. Press seam allowances towards back part and serge. Stitch loosely along top edge and draw so the length was equal to lower edge of upper part. Stitch lower part to upper part, press and serge seam allowances.
12. Cut a piece of elastic, that is equal to waist girth and topstitch it, stretching it, onto seam allowance of upper and lower parts connecting seam.
13. Serge hem of the garment, press onto wrong side and topstitch.
14. Serge one long edge of the belt loop. Fold the belt loop into three layers and topstitch on long sides. Cut the belt loop in 2 details. Sew belt loops on waist on side seams.
15. Fold belt in half lengthwise right sides together and overstitch along the long and short sides, leaving a slit to turn belt out. Turn belt onto right side, press. Sew the slit.

TECHNICAL DRAWING:

