

Sewing Pattern — Dress 5558

Recommendations on fabric: silk/viscose.

You will also need: fusing; 7 buttons

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: 1 cm for all seams, 3 cm for garment/sleeve hems

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

- 1. Collar 2 pieces
- 2. Stand-up collar 2 pieces
- 3. Center back part 2 pieces
- 4. Side back part 2 pieces
- 5. Side front part 2 pieces
- 6. Center front part 2 pieces
- 7. Front band 2 pieces
- 8. Sleeve 2 pieces

<u>Fusing:</u> front band, outer collar, stand-up collar.

INSTRUCTIONS:

- 1. Apply the fusing to wrong side of front band, outer collar and stand-up collar.
- 2. Stitch front relieves and neaten them. Press relieves toward front center.
- 3. Stitch back relieves and neaten them. Press relieves toward back center.
- 4. Neaten middle back seam, stitch it and press it.



- 5. Neaten front bands' inner edge.
- 6. Pin front band on front part right sides together and overstitch along edging. (Overstitching goes upwards at front part side.) Stitch front bands' lower edges to front part along hem line. Cut front edgings lower corners' seams. Topstitch front edgings' overstitching allowances on front bands at 0.2 cm from seams. Turn front edgings right side out.
- 7. Neaten shoulder seams, stitch them and press them backwards.
- 8. Neaten side seams, stitch them and press them backwards.
- 9. Overstitch inner collar with outer cone, cut corner allowance and turn the collar right side out. Press them collar.
- 10. Stitch stand-ups together inserting the collar between them.
- 11. Stitch inner stand-up with the collar into neckline, fold outer stand-up under and topstitch along the seam joining inner stand-up. Topstitch the collar.
- 12. Stitch sleeve edges. Neaten sleeve seam and press it.
- 13. Stitch sleeves in easing them along sleeve caps. Neaten joining seam.
- 14. Neaten dress/sleeve hems, fold them into wrong side and topstitch along edges.
- 15. Make buttonholes into right front edging, sew buttons on left one.

TECHNICAL DRAWING:

